



		STANDARD	1-1-01
FRONT SUSPENSION		PERS	1-001

REP	NUM_ART	DESC	QTY
01	WG9232520025	Front Leaf Spring LH	1
03	WG9232520025+001/1	Front Leaf Spring LH 1	1
04	WG9232520025+002/1	Front Leaf Spring LH 2	1
05	WG9232520025+003/1	Front Leaf Spring LH 3	1
06	WG9232520025+004/1	Front Leaf Spring LH 4	1
07	WG9232520025+005/1	Front Leaf Spring LH 5	1
08	WG9232520025+006/1	Front Leaf Spring LH 6	1
09	WG9232520025+007/1	Front Leaf Spring LH 7	1
10	WG9232520025+008/1	Front Leaf Spring LH 8	1
11	WG9232520025+009/1	Front Leaf Spring LH 9	1
12	WG9232520025+010/1	Front Leaf Spring LH 10	1
13	WG9232520025+012/1	Conter Bolt	1
14	WG9232520025+013/1	Nut, Center Bolt	1
15	WG9232520026	Front Leaf Spring Assy	1
17	WG9232520026+001/1	Front Leaf Spring RH 1	1
18	WG9232520026+002/1	Front Leaf Spring RH 2	1
19	WG9232520026+003/1	Front Leaf Spring RH 3	1
20	WG9232520026+004/1	Front Leaf Spring RH 4	1
21	WG9232520026+005/1	Front Leaf Spring RH 5	1
22	WG9232520026+006/1	Front Leaf Spring RH 6	1
23	WG9232520026+007/1	Front Leaf Spring RH 7	1
24	WG9232520026+008/1	Front Leaf Spring RH 8	1
25	WG9232520026+009/1	Front Leaf Spring RH 9	1
26	WG9232520026+010/1	Front Leaf Spring RH 10	1
27	WG9232520026+012/1	Conter Bolt	1
28	WG9232520026+013/1	Nut, Center Bolt	1
29	WG9000520078	Bush	4
31	WG9100520034	Hanger ass. -front spring	2




		STANDARD	1-1-01
FRONT SUSPENSION		PERS	1-002

REP	NUM_ART	DESC	QTY
33	WG9100520065	Spring pin	6
35	1680520050	Washer	12
36	Q151C1270	Screw	2
37	Q151C1275	Screw	4
38	190003888457	Nut	6
39	AZ9003963022	Grease Nipple	6
42	WG9725520168	Plate	2
44	AZ9925520027	U Bolt	2
45	AZ9925520028	U Bolt	2
46	Q33020T13F2	Nut	8
47	WG9323520010	Stop	2
52	WG9731520034	Stop Block Assy	2
54	Q150B1240	Hex Screw	4
55	Q150B1230	Hex Screw	4
56	Q33212	Nut	8
57	AZ9725520007	Bracket	2
62	Q151B1660	Hex Screw	8
63	190003888459	Lock Nut	8
64	WG9232520010	Bracket LH	1
66	WG9232520011	Bracket RH	1
68	Q151B1650	Hex Screw	6
69	190003888459	Lock Nut	6
70	Q151C1260	Hex Screw	16
71	190003888457	Lock Nut	16




		STANDARD	1-1-02
FRONT SHOCK ABSORBERS + FIXING		PERS	1-004

REP	NUM_ART	DESC	QTY
01	WG9100680002	Front shock absorber	2
03	WG9925680026	Bracket	2
05	Q151C1235	Screw	8
06	190003888457	Nut	8
07	199100680021	Plate	4
08	199100680036	Screw	2
09	Q40016	Washer	2
10	190003888459	Nut	2
11	Q151B16100	Screw	2
12	190003888459	Nut	2




		STANDARD	1-1-03
FRONT STABILIZER + RODS		PERS	1-005

REP	NUM_ART	DESC	QTY
01	WG9925680004	Front Stabilizer bar	1
03	AZ9719680091	Bracket	1
04	AZ9719680093	Bracket	1
05	199100680054	Sleeve	1
07	AZ9719680092	Bracket	1
08	AZ9719680094	Bracket	1
11	190003936012	Washer	2
12	Q151C1250	Screw	4
13	190003888457	Nut	4
14	AZ9160680055	Plate	2
15	AZ9160680056	Plate	2
16	199100680057	Screw	2
17	190003888459	Nut	2
18	Q40016	Washer	2
19	199100680069	Screw	2
21	190003888458	Lock Nut	2
22	Q40214	Washer	2
23	199100680068	Rubber Bush	2
24	WG9925680011	Clip	2
26	WG9925680012	Plate	2
28	Q150B1030TF2	Screw	4
29	Q40310	Spring Washer	4




		STANDARD	1-1-04
REAR STABILIZER BAR		PERS	1-005.1


REP	NUM_ART	DESC	QTY
04	190003888459	Nut	6
05	WG9719680006	Rear Stabilizer bar	1
07	WG9719680061	Clip	2
10	199100680037	Sleeve	2
11	199100680066	Bush	4
12	WG80 680029	Screw	2
13	1780 680029	Screw	1
16	1780 680030	Washer	2
17	190003930010	Washer	2
18	190003888459	Nut	2
19	199100680067	Rubber Bush	2
20	WG780 680032	Clip	2
22	Q151C12100	Screw	4
23	190003888457	Nut	4
24	WG80 680029	Screw	2
25	1780 680029	Screw	1
28	1780 680030	Washer	2
29	190003888459	Nut	2
32	199100510008	Bracket	2
33	Q151B1650	Screw	4
34	Q151B1655	Screw	2
35	WG9100680071	Washer	2





		STANDARD	1-2-01
BOGIE & REACTION ROD		PERS	1-006
REP	NUM_ART	DESC	QTY
02	AZ9925520310	Bogie	2
32	AZ9725520250	Guide plate	4
33	Q40312	Spring Washer	16
34	Q151C1255	Screw	16
35	Q151B20120	Screw	4
36	Q40120	Washer	4
37	Q151B1670	Hex Screw	24
38	AZ9003860003	screw	8
39	Q151B1675	Screw	2
40	AZ9003860004	screw	4
41	190003888459	Lock Nut	38
42	Q151B1680	Hex Screw	16
43	190003888459	Lock Nut	16
44	WG9725520286	Rear Leaf Spring Assy	2
46	WG9725520286+001/1	Rear Leaf Spring Assy 1	1
47	WG9725520286+002/1	Rear Leaf Spring Assy 2	1
48	WG9725520286+003/1	Rear Leaf Spring Assy 3	1
49	WG9725520286+004/1	Rear Leaf Spring Assy 4	1
50	WG9725520286+005/1	Rear Leaf Spring Assy 5	1
51	WG9725520286+006/1	Rear Leaf Spring Assy 6	1
52	WG9725520286+007/1	Rear Leaf Spring Assy 7	1
53	WG9725520286+008/1	Rear Leaf Spring Assy 8	1
54	WG9725520286+009/1	Rear Leaf Spring Assy 9	1
55	WG9725520286+010/1	Rear Leaf Spring Assy 10	1
56	WG9725520286+011/1	Rear Leaf Spring Assy 11	1
57	WG9725520286+012/1	Rear Leaf Spring Assy 12	1
58	WG9725520286+013/1	Center Bolt	1
59	WG9725520286+014/1	Nut	1
60	199000520006	导向销	4
61	AZ9925520268	U Bolt	8



		STANDARD	1-2-01
BOGIE & REACTION ROD		PERS	1-007
REP	NUM_ART	DESC	QTY
63	WG9925520269	Nut	16
65	AZ9725529272	V Rod	2
90	AZ9714520227	Stud	8
91	190003871353	Nut	8
92	Q40318	Spring Washer	8
93	AZ9631523175	Reaction Rod	4
103	190003888467	Lock Nut	12
106	Q150B1460	Screw	12
107	Q150B1450	Screw	4
108	Q40314	Spring Washer	16
109	AZ9725520278	Spring Mounting	4
110	WG9725520277	Bracket -left rear	2
112	WG9725520279	Bracket -ringt rear	2
114	Q151B1430TF2	Hex Screw	16
115	Q40314	Spring Washer	16
116	AZ9725520290	Bracket	1
117	AZ9725520291	Bracket	1
118	AZ9725520294	Bracket	1
119	AZ9725520295	Bracket	1
120	Q151B22250	Hex Screw	16
121	190003888630	lock nut	16
122	190003901905	Pin	4
123	WG9925520366	Bracket	2
142	WG9725520367	Spacer	8
144	Q18422110TF2	Hex Screw	8
145	Q151B20180TF2	Hex Screw	4
146	Q151B20100TF2	Hex Screw	8
147	WG9725520776	Limit block	4





				STANDARD	1-2-02
CHASSIS FRAME				PERS	1-011
REP	NUM_ART	DESC	QTY		
02	AZ9727514111	横梁右上连接板	1		
03	AZ9727514112	半圆头铆钉	1		
04	AZ9727514113	半圆头铆钉	1		
05	AZ9727514114	六角头螺栓	1		
09	AZ9727510115	横梁上连接板	1		
17	AZ9731513265	右连接板（与左对称）	1		
25	AZ9725516006	后支撑板	1		
34	AZ9725514111	半圆头铆钉	2		
35	AZ9625510476	六角头螺栓	2		
39	AZ9731513280	横梁左上连接板	1		


		STANDARD		2-1-01
气缸体（一） Cylinder Block		PERS		2-001
REP	NUM_ART	DESC	QTY	
00	61500010383	Cylinder block assembly	1	
01	61500010356B	Cylinder block	1	
02	61500010366C	Crankcase	1	
03	VG1500010344	Cylinder liner	6	
04	190003982121	Core hole plug	4	
05	190003989480	Core hole plug	1	
06	190003989204	Core hole plug	1	
07	VG1560010029	Camshaft bush	6	
07.1	VG2600010990	Camshaft bush	1	
08	90003901604A	Straight pin	2	
08.1	Q5211220	Straight pin	1	
09	VG1500010046	Sleeve bearings	7	
10	VG1500010125	Thrust washers	1	
11	VG14010114	Headstock bolt	13	
11.1	VG14010217	Headstock bolt	1	
12	190003802493	Hex head bolt	27	
13	VG1400010032	Sealing ring	2	
14	190003989210	Core hole plug	9	
15	VG2600070097	Oil return elbow connector	1	
16	190003989289	Core hole plug	4	
17	190003989215	Core hole plug	4	
18	190003962621	Hollow bolt	6	
19	VG9003080005	Sealing washer	6	
20	VG2600010659	Oil injection nozzle	6	
21	190003909603	Spring type straight pin	6	
22	VG1500010047	Rear oil seal	1	
23	190003989288	Core hole plug	1	
24	VG1460070011	Main oil gallery screw plug	1	
25	VG2600010735	Sealing washer	1	

		STANDARD	2-1-01
气缸体（一） Cylinder Block		PERS	2-002


REP	NUM_ART	DESC	QTY
26	VG407010046	Sealing ring	1
27	190003984080	Core hole plug	1
28	VG1500010215	Cylinder head stud	7
29	190003901604	Straight pin	6
30	190003909626	Spring type straight pin	6
31	VG1500010189	Cylinder head stud	14
32	VG288730061	Sealing ring	1
33	VG61000010134	Sealing ring	1




		STANDARD		2-1-02
气缸体（二） Cylinder Block		PERS		2-003
REP	NUM_ART	DESC	QTY	
01	61557010008	Gearcase	1	
02	VG2600010830	Air compressor gear cover	1	
03	VG14010040	Gasket	1	
04	VG2600010928	Front oil seal carrier	1	
05	VG1500010037	Front oil seal	1	
06	VG1500010008A	Camshaft gear cover	1	
07	VG14010070	Gasket	1	
08	190003813429	Stud	14	
09	190003932023	Wave spring washer	17	
10	190003900085	Spring type Straight pin	4	
11	190003802576	Hex head bolt	1	
12	190003932024	Wave spring washer	1	
13	190003800571	Hex head bolt	1	
14	190003931122	Spring lockwasher	10	
15	190011260039	Hex head bolt	6	
16	190003862524	Socket cap screw	2	
17	190003932025	Saddle shaped spring washer	2	
18	190003871252	Hexagon nut	17	
19	190003813443	Stud	1	
20	190003962051	Screw plug	1	
21	190003901507	Straight pin	4	
22	190003802523	Hex head bolt	3	
23	190011620016	Stud	2	
24	190003813628	Stud	6	
25	190003888453	Self-locking nut	8	
26	190003813467	Stud	2	
27	VG9003080001	Sealing washer	6	
28	VG2600010934	Front oil seal carrier gasket	1	
29	190003930271	Flat washer	2	
30	190003802561	Hex head bolt	6	


				STANDARD	2-1-03
气缸体（三） Cylinder Block				PERS	2-004
REP	NUM_ART	DESC	QTY		
01	VG1540010014A	Oil cooler cover	1		
02	VG1540010015A	Gasket	1		
03	AZ1500010012	Flywheel housing	1		
04	VG1800210011	Observation hole cover	1		
05	VG2600010705	Lower oil dipstick subassembly	1		
06	VG1500010600	Upper oil dipstick subassembly	1		
07	190003098014	Sealing washer	1		
08	190003962020	Screw plug	1		
09	190003932023	Wave spring washer	18		
10	190003800467	Hex head bolt	8		
11	190003802437	Hex head bolt	10		
12	VG1500010031	Bolt	1		
13	VG2600010647	Clamp	1		
14	VG2600010638	Rubber pipe clamp	1		
15	190003802411	Hex head bolt	1		
16	190003802511	Hex head bolt	2		
17	VG1500010062	Hex head bolt	7		
18	190003871305	Hexagon nut	12		
19	190003931122	Spring lockwasher	12		
20	190003813537	Stud	10		
20	190003813544	Stud	2		
21	190003813527	Stud	3		
22	190003888452	Self-locking nut	3		
23	190003901604	Straight pin	2		
24	VG1500019045A	Oil separator	1		
25	VG12G00040038	Hose	1		
26	190003989301	Hose clamp	1		
27	190003989336	Hose clamp	2		
28	VG2600011106	Hose	1		
29	VG14010086	Oil filler gasket	1		

		STANDARD	2-1-03
气缸体 (三) Cylinder Block		PERS	2-005
REP	NUM_ART	DESC	QTY
30	VG1560010028	Oil filler	1
31	190003931082	Spring lockwasher	4
32	190003802321	Hex head bolt	4
33	190003989306	Hose clamp	2
34	VG1500010079	Hose	1
35	VG2600010919	Oil filler neck	1
36	VG2600010489	Oil filler cap	1
37	Q734B2650265	Sealing ring	1

		STANDARD		2-1-04
曲轴飞轮 Crankshaft and Flywheel		PERS		2-006
REP	NUM_ART	DESC	QTY	
00	161560020029	Crankshaft assembly	1	
01	161560020024	Crankshaft	1	
02	VG14020038	Crankshaft gear	1	
03	VG1500020070	Flange	1	
04	VG1560020010	Vibration damper	1	
05	VG1560020020	Belt pulley	1	
06	190003802558	Hex head bolt	8	
07	VG2600020253	V-belt	2	
08	190003901504	Straight pin	6	
09	190003960569	Straight key	1	
10	190003901418	Straight pin	1	
11	VG2600020208	Starter ring gear	1	
12	AZ1500020220A	Flywheel	1	
13	190003813571	Stud	2	
14	190003932024	Wave spring washer	12	
15	190003871305	Hexagon nut	2	
16	190003311416	Ball bearing	1	
17	190003934310	Retaining ring	1	
18	VG1500020046	Hex head bolt	9	
19	190003800579	Hex head bolt	10	


				STANDARD	2-1-05
活塞连杆 Piston and Connecting Rod				PERS	2-007
REP	NUM_ART	DESC	QTY		
01	VG1560037011	Piston	6		
02	VG1560030013	Piston pin	6		
03	VG1560030012	Retaining ring	12		
04,5,6	VG1560030050	Spring-backed oil piston ring	1		
07	161500030009	Connecting rod assembly	6		
08	161500030022	Connecting rod cover	6		
09	VG1500030077	Connecting rod bush	6		
10,11	VG1560030034/33	Con Rod bearing	1		
12	VG1500030023	Connecting rod bolt	12		

		STANDARD		2-1-06
气缸盖 Cylinder Head		PERS		2-008
REP	NUM_ART	DESC	QTY	
00	161560040058	Cylinder head assembly	6	
01	61560040040A	Cylinder head	6	
02	VG1560040057	Intake valve seat	6	
03	VG1560040037	Exhaust valve seat	6	
04	VG1560040031	Valve guide	12	
05	VG1406060010	Sealing ring	6	
06	VG1560040049	Nozzle holder insert	6	
07	190003989294	Core hole plug	24	
08	190003989277	Core hole plug	6	
09	190003989721	Core hole plug	6	
10	190003989725	Core hole plug	6	
11	VG1500040049	Cylinder head gasket	6	
12	VG14040065	Cylinder head cover	6	
13	VG14040021	Cylinder head cover gasket	6	
14	VG1500040104	Water drain pipe	1	
15	VG1500060045	Pipe connection assembly	1	
16	VG1500040105	pipe	1	
17	VG1200040027	Cylinder head clamp	2	
18	VG1200040034	Collar nut	7	
19	VG1500040106	Gasket	1	
20	VG1200040023A	Cylinder head clamp	5	
21	VG1560040032	Valve guide bush	12	
22	VG1500040023	Cylinder head bolt	24	
23	190003800466	Hex head bolt	24	
24	190003932023	Wave spring washer	36	
25	Q1200825F3	Stud	2	
26	190003871252	Hexagon nut	12	
27	190014040007	Wash	4	
28	190003802432	Hex head bolt	4	
29	Q1200870	Stud	2	





		STANDARD	2-1-06
气缸盖 Cylinder Head		PERS	2-009

REP	NUM_ART	DESC	QTY
30	VG1500040012	Cylinder head clamp	2
31	VG14010388	Bolt	2
32	VG1500040009	Cylinder head clamp	5





		STANDARD		2-1-07
配气机构 Valve Train		PERS		2-010
REP	NUM_ART	DESC	QTY	
00	VG1500050097	Camshaft assembly	1	
01	VG1500050096	Camshaft	1	
02	VG14050133	Thrust flange	1	
03	VG14050053	Camshaft gear	1	
04	VG1540059032	Intermediate gear Joint	1	
05	VG1540059031	Idle gear axle	1	
06	VG1560050054	Holder	1	
07	VG1560050053	Idle gear	1	
08	VG1560050045	Guard plate	1	
09	190003120602	Sealing ring	1	
10	VG1560050046A	Cover	1	
11	VG14050049	Rocker arm (exhaust)	6	
12	VG14050010	Valve setting screw	12	
13	VG1500050070	Push rod	12	
14	VG1500050032	Valve tappet	12	
15	VG14050119	Rocker arm support	6	
16	VG1500050025	Valve cone	24	
17	VG1500050109	Spring cup	12	
18	VG1500050002	Outer valve spring	12	
19	VG1500050001	Inner valve spring	12	
20	VG1560050041	Exhaust valve	6	
21	VG14050048	Rocker arm (intake)	6	
22	VG1560051001	Intake valve	6	
23	190003802399	Hex head bolt	2	
24	190003901409	Straight pin	1	
25	190003802443	Hex head bolt	4	
26	VG1560050059	Hex head bolt	4	
27	190003932023	Wave spring washer	3	
28	190003862419	Socket cap screw	1	
29	VG2130050065	Hexagon nut	12	




				STANDARD	2-1-08
排气系统 Exhaust System				PERS	2-012
REP	NUM_ART	DESC	QTY		
01	VG2600111137	Exhaust manifold (front)	1		
02	VG2600111136	Exhaust manifold (rear)	1		
03	VG2600111142	Heat insulation cover (front)	1		
04	VG2600111143	Heat insulation cover (rear)	1		
05	VG1500110963	Heat-resistant bolt	12		
06	VG260110162	Laminated sealing ring	4		
07	VG1560110111	Gasket	6		
08	VG2600111052	Bolt	12		
09	VG1560110241	Hex head bolt	4		
10	VG1560118229	Turbocharger	1		
11	VG1560110210	Gasket	1		
12	VG1092110043	Oil supply pipe	1		
13	VG1560110152		1		
14	VG609E110050	Gasket	1		
15	190003862428	Socket cap screw	2		
16	VG188250083	Lockwasher	4		
17	VG1560079003	Oil return pipe	1		
17	VG1560079025		1		
18	VG2600110048	Gasket	1		
19	VG1460070014	Bolt	2		
20	190003989340	Hose clamp	2		
21	VG2600070071	Hose	1		
22	190003937282	Washer	12		

		STANDARD	2-1-09
进气系统 Air Intake System		PERS	2-013
REP	NUM_ART	DESC	QTY
01	VG2600110812	Intake manifold	1
02	190003962014	Screw plug	1
03	VG9003080003	Sealing washer	1
04	VG1500110024	Gasket	6
05	190003800465	Hex head bolt	6
06	190003962621	Hollow bolt	1
07	VG14110064	Bolt	4
08	190003800497	Hex head bolt	2
09	190003932023	Wave spring washer	22
11	VG1560110165	Elbow connector	
12	VG1560110226	Clamp	2
13	VG190320035	Sealing ring	2
15	VG9112530148	Hose	1
18	VG9003980003	Hose clamp	2
20	VG609E110036	Adjusting washer	2
21	190003802411	Hex head bolt	6
22	VG1560110021	Tension strap	2
23	VG209190017	Clamping pin	2
24	VG1700550013	Clamping pin	2
25	190003862462	Socket cap screw	2
27	VG9100570019	Suspension bracket	1
29	VG9003080008	Sealing washer	2
31	VG2600111078	Elbow connector	1
31	VG2600111141	Elbow connector	1
32	VG1800110045	Elbow connector	1
33	VG1047110103	Hose	1
34	VG1047110104	Pipe	1
38	VG1047110105	Mounting plate	1
39	VG2600111196	Pipe	1
40	190003802415	Hex head bolt	2



		STANDARD	2-1-09
进气系统 Air Intake System		PERS	2-014
REP	NUM_ART	DESC	QTY
41	Q150B0818	Hex head bolt	2
			


				STANDARD	2-1-10
机油滤清器和机油冷却器 Oil Filter and Oil Cooler				PERS	2-015
REP	NUM_ART	DESC	QTY		
01	VG1500070051	Oil filter body	1		
02	VG61000070005	Oil filter	2		
03	VG1500010334	Oil cooler	1		
04	VG1400010032	Sealing ring	2		
05	190003962051	Screw plug	1		
06	VG2600010735	Sealing ring	1		
07	VG14070068	Valve spring	1		
08	VG14070069	Valve cone	1		
09	VG1500070097	Discharging valve assembly	1		
10	190003862443	Socket cap screw	2		
11	190003932023	Wave spring washer	6		
12	VG1500070011	screw	2		
13	190003862419	Socket cap screw	4		

				STANDARD	2-1-11
双缸空气压缩机 Double Cylinder Air Compressor				PERS	2-016
REP	NUM_ART	DESC	QTY		
01	VG1560130080A	Air compressor assembly	1		
02	VG1560130064	Injection pump gear	1		
03	VG409020045	Washer	1		
04	VG2600130045	Hexagon nut	1		
05	VG2600130026	Water pipe connector	2		
06	190003989336	Hose clamp	4		
07	VG1560060018	Hose	1		
08	VG1560130035	Intake pipe connector	1		
09	190003559778	Nut	1		
10	VG1560060012	Water inlet connector	1		
11	VG1560060019	Hose	1		
12	190003802419	Bolt	7		
13	190003932023	Wave spring washer	7		
14	VG1560070051	Transition joint	2		
15	19003080003	Washer	7		
16	VG2600130053	Bolt	1		
17	Q351B14	Nut	1		

		STANDARD		2-1-12
冷却系统 Cooling System		PERS		2-017
REP	NUM_ART	DESC	QTY	
01	VG1500060051	Water pump assembly	1	
02	VG1500060240	Flange	1	
02	VG1500060241	Flange	1	
05	VG2600060446	Ring fan	1	
05	VG1500060402	Viscous fan	1	
06	VG14060024	Gasket	1	
07	VG1560060023	Intake nozzle	1	
08	VG1560060004	Pipe connector	1	
09	190003989336	Hose clamp	2	
10	VG2600060456	Water pump seal assembly	1	
11	190003989308	Hose clamp	2	
12	VG61000060276	Hose	1	
13	VG1047060001	Thermostat	1	
13	VG1047060005	Thermostat	1	
13-1	VG1500061203	Thermostat body	1	
13-2	VG1047060004	Water seal	1	
13-3	VG1047060002	Thermostat core	1	
13-3	VG1047060003	Thermostat core	1	
14	VG140608	Gasket	1	
15	VG1500060001	Support	1	
16	Q218B1625	Socket cap screw	1	
17	VG2600060313	Tensioning roller assembly	1	
17	VG1062060112	Tensioning roller assembly	1	
19	VG1095060006	Mounting bracket l.	1	
20	VG1095060009	Mounting bracket r.	1	
21	190003813148	Stud	6	
21	190003810020	Stud	6	
23	190003802424	Hex head bolt	7	
24	190003800467	Hex head bolt	1	
25	190003888452	Self-locking nut	6	


		STANDARD	2-1-12
冷却系统 Cooling System		PERS	2-018
REP	NUM_ART	DESC	QTY
27	190003888451	Self-locking nut	6
28	190003932023	Wave spring washer	2
29	190003931182	Spring lockwasher	1

		STANDARD	2-1-13
供油系/Fuel Supply System		PERS	2-019
REP	NUM_ART	DESC	QTY
01	VG1560080023	Fuel pump Assy	1
1.1	VG1560080023-XLB	Fuel Pump Repair Kit	
1.2	170S	Pump Plunger	
02	VG1560080300	Coupling ass.	1
2.01	VG1560080279	Coupling flange	1
2.02	VG1560080219	Flexible driving plate	12
03	190003901600	Cylinder pin	2
04	VG1500080174	Bracket	1
05	190003931142	Spring washer	6
06	Q150B1295	Screw	3
07	Q150B1285	Screw	1
08	Q150B1245	Screw	2
09	VG2600080200	Washer	14
10	190003962621	Female screw	7
11	VG1560070025	Oil return tube	1
12	190003930271	Washer	4
13	VG18872339	Washer	4
14	190003800571	Screw	4
15	VG1500080090	Female Screw	6
16	VG9003080001	Washer	12
17	VG1500080095	Fuel return line	1
18	190003962612	Female screw	1
19	VG9003080004	Washer	2
20	VG1560080284	Air pipe	1
21	VG1560080278A	Injection pipe	1
22	VG2600080383	Screw	12
23	190003932023	Spring washer	12
24	VG1500080094A	Plate	6
25	VG1560080276	Fuel injector ass	6
25.1	VG1095088005	Nozzle	6




		STANDARD	2-1-13
供油系/Fuel Supply System		PERS	2-020

REP	NUM_ART	DESC	QTY
25.2	VG1095088002	Plunger ass.	6
25.3	VG1095088004	Delivery valve ass.	6
26	VG609070080	Washer	6
27	VG14080082	Washer	6





		STANDARD	2-1-14
燃油滤清器部分(M+H)/Fuel Filter		PERS	2-021

REP	NUM_ART	DESC	QTY
01	VG1560080012	Fuel Filter	1
01.1	VG1560080013	Seat	1
02	VG1540080311	Fuel Prefilter	1
02.1	VG1540080314	Seat	1
03	VG1092080019	Fuel pipe	1
04	VG1092080017	Fuel pipe	1
05	VG1092080018	Fuel pipe	1
06	VG1092080026	Bracket	1
07	VG1540080027	Bracket	1




		STANDARD	2-1-15
机油泵和机油滤清器/Oil Pump and Oil Filter		PERS	2-022
REP	NUM_ART	DESC	QTY
01	190003802578	Screw	1
02	VG14070155	Washer	1
03	VG14070056	Shaft	1
04	190003311410	Ball bearing	2
05	190003934732	Ring	1
06	VG14070049	Ring	1
07	VG14070061	Gear	1
08	190003800551	Screw	1
09	190003931122	Spring washer	2
10	190003802527	Screw	1
11	VG1500070021	Oil pump	1
12	VG14070055	Gasket	1
13	VG140778	Gasket	1
14	190003932025	Spring washer	2
15	190003802523	Screw	2
16	VG1800070051	Suction pipe	1
17	VG1500070097	Pressure limit valve	1
18	190003932023	Spring washer	4
19	190003862443	Screw	2
20	VG61000070005	Oil filter	2
21	VG1500070051	Oil filter base ass	1
22	VG1500010334	Oil radiator	1
23	190003862419	Screw	4
24	190003932023	Spring washer	4
25	VG1400010032	Washer	2
26	190003962051	Plug	1
27	VG2600010735	Washer	1
28	VG14070068	Spring-for safety valve	1
29	VG14070069	Safety valve	1




				STANDARD	2-1-16
油底壳 Oil Sump				PERS	2-023
REP	NUM_ART	DESC	QTY		
01	VG1800150015A	Oil sump assembly	1		
02	VG14150004	Seal	1		
03	VG2600150108	Magnetic screw plug	1		
04	VG2600150106	Sealing washer	1		
05	190003802442	Hex head bolt	12		
06	190003932023	Wave spring washer	12		
07	190003930261	Flat washer	12		
08	VG14150046	Retainer	12		

		STANDARD		2-1-17
电气系统 Electrical System		PERS		2-024
REP	NUM_ART	DESC	QTY	
01	VG1560090001	Starter motor	1	
02	VG1500090027	Tension block	1	
03	VG1500090066	Belt	2	
04	VG581C160018	Bush	2	
05	VG1560090012	Alternator	1	
06	VG1500130027	Spacer block	1	
07	190003935125	Flat washer	2	
08	190003802558	Hex head bolt	1	
09	190003932025	Saddle shaped spring washer	2	
10	190003871305	Hexagon nut	1	
11	VG1500090039	Tension bolt	1	
12	VG1500090026	Tension bolt	1	
13	VG1500090060	Oil pressure sensor	1	
14	VG1500090061	Water temperature sensor	1	
15	VG1500130018A	Bracket	1	
16	VG2600080275	Sealing washer	1	
17	VG9003080005	Sealing washer	1	
18	190003800568	Hex head bolt	1	
19	VG1500130019	Bush	1	
20	190003888452	Self-locking nut	1	
21	190003802527	Hex head bolt	1	
22	190003930271	Flat washer	1	
23	190003800568	Hex head bolt	1	
24	190003888452	Self-locking nut	1	
25	190003802424	Hex head bolt	2	
26	190003932023	Wave spring washer	2	
27	190003932309	Flat washer	2	
28	190012630006	Hexagon nut	2	
29	190003935015	Flat washer	2	
30	190003931162	Spring lockwasher	1	




		STANDARD		2-1-17
电气系统 Electrical System		PERS		2-025
REP	NUM_ART	DESC	QTY	
31	190003802432	Hex head bolt	1	
32	190003800575	Hex head bolt	1	
33	190014040007	Flat washer	1	
34	190014070002	Washer	1	

		STANDARD		2-1-18
SENSOR		PERS		2-029
REP	NUM_ART	DESC	QTY	
01	VG1500090061	六角头螺栓	1	
03	VG9003080005	六角头螺栓	1	
06	VG1092090311	弹簧垫圈	1	
08	VG2600080275	圆柱销	1	
11	VG2600090318	平垫圈	1	
14	VG2600090319	自锁垫圈	1	
17	VG1095090139	联轴器总成	1	


			STANDARD	2-2-01
油门操纵系统/Accelerator Control System			PERS	2-030
REP	NUM_ART	DESC	QTY	
1	AZ9725570020	Pedal pad	1	
2	190003171697	Fastener	3	
3	WG9012570084	Shaft	1	
4	Q40110	Washer	1	
5	Q5003216	Split pin	1	
6	190003963623	Ball joint	1	
7	Q340B08	Nut	1	
8	WG9100570014	Exhaust Brake Cylinder For Cut Oil	1	
9	Q340B10	Nut	1	
10	WG9012570062	Screw	1	
11	Q340B08	Nut	1	
12	WG92 570025	Ball joint	1	
13	190003936513	Clamp	1	
14	Q340B06	Nut	1	
15	WG9003963313	Ball pin	1	
16	Q40506	Spring washer	1	
17	190003936514	Clamp	1	
18	Q150B0650Q	Screw	1	
19	Q340B06	Nut	1	
20	Q43680	Ring	1	
21	WG99014180012	sleeve	1	
22	AZ9725570100	Lever	1	
23	199100570065	Spring	1	
24	AZ9725570057	Washer	1	
25	WG9716570002	Controller cable	1	
26	Q5002014	Split pin	1	
27	Q40106	Washer	1	
28	AZ9725570041	bracket	1	
29	Q150B0820	Screw	1	
30	Q40308	Spring washer	1	
31	Q340B08	Nut	1	


				STANDARD	2-3-02
TURBOCHARGE				PERS	2-037
REP	NUM_ART	DESC	QTY		
01	VG1560118229	燃油箱支架总成	1		




			STANDARD	2-3-03
TURBOCHARGE PIPING			PERS	2-038
REP	NUM_ART	DESC	QTY	
01	VG1560079003	燃油箱支架	1	
03	VG1560079004	加强支架	1	
04	VG1560110039	加强板	1	
06	VG1560079004	板	1	
07	VG1560110039	D型燃油箱垫带 (400L)	1	

				STANDARD	2-3-04
TURBOCHARGE PIPING				PERS	2-039
REP	NUM_ART	DESC	QTY		
01	VG2600111078	D型燃油箱紧固带 (400L)	1		





				STANDARD	2-3-05
RADIATOR & INTERCOOLER				PERS	2-040
REP	NUM_ART	DESC	QTY		
01	WG9719530231	RADIATOR ASSY	1		
02	WG9719530250	INTERCOOLER	1		


		STANDARD		2-3-06
OIL TANK, FIXING		PERS		2-041
REP	NUM_ART	DESC	QTY	
01	WG9725550006	拉紧销	1	
04	WG9625550131	拉紧销	1	
06	AZ9112550220	内六角螺栓	2	
08	AZ9112550221	管接头(12X1.5-M16)	1	
09	AZ9112550222	空心螺栓	1	
10	AZ9112550223	软管接头	1	
12	199112550128	聚酰胺管 无色透明	2	
14	WG9725550010	聚酰胺管 无色透明	2	
15	WG9725550009	聚酰胺管 无色透明	2	
16	AZ9112550227	塑料紧箍带	2	
17	AZ9112550228	聚酰胺管	2	
18	AZ9112550229	穿线护套	2	
20	AZ9112550230	穿线护套	2	
21	WG9725550004	穿线护套	2	
22	190003962627	柴油粗滤器支架	2	
23	WG9014230031	弯板	2	
25	AZ9725550120	六角头螺栓	545	
26	AZ9725550120	2型全金属六角锁紧螺母	545	
27	AZ9725550120	六角头螺栓	80	
28	190003171697	2型六角螺母	6	
29	AZ9112550121	平垫圈	50	
30	190003179046	弹簧垫圈	130	
31	190003179046	复合密封垫圈16 QZZ21052	100	
32	190003179046	六角头螺栓	100	
33	AZ9725550101	2型全金属六角锁紧螺母	1	
34	AZ9725550102	1540W交流发电机	2	
36	Q150B1065	发电机多楔带	2	
37	Q33210	压紧块	2	
38	Q151B1650TF3	六角头螺栓	4	
39	Q361B16T13F3	鞍形弹性垫圈	4	


			STANDARD	2-3-06
OIL TANK, FIXING			PERS	2-042
REP	NUM_ART	DESC	QTY	
40	Q40116	拉紧螺栓(参图1413C 090014)	4	
41	Q40316	拉紧块	4	
42	AZ9003090016	平垫圈	4	
43	Q150B1035	1型六角螺母	2	
44	Q33210	2型全金属六角锁紧螺母	2	

The diagram illustrates the assembly of an oil tank. The main component is the oil tank (1). It features a top cover (12) and a side cover (14). The top cover is secured by four tension bolts (40) and four tension blocks (41). The side cover is secured by two hexagonal nuts (43) and two full metal hexagonal lock nuts (44). The assembly also includes various other components such as washers (42), gaskets (3), and fasteners (31, 30, 3, 27, 20, 37, 26, 29, 17, 19, 16, 45, 46, 34, 36, 28, 22, 44, 24, 18). The diagram shows the relative positions and assembly sequence of these components.


				STANDARD	2-7-01
ENGINE SUSPENSION				PERS	2-046
REP	NUM_ART	DESC	QTY		
2	AZ9725590101	Crossbar	1		
13	WG1680590095	Mounting Front	2		
26	AZ9731590081	Bracket	1		
27	AZ9731590082	Bracket	1		
30	AZ9725590031	Mounting Rear	2		
38	AZ9725590002	Support	1		
42	AZ9725590006	Support	1		

				STANDARD	2-8-01
冷却系统/Cooling System				PERS	2-047
REP	NUM_ART	DESC	QTY		
01	WG9725533038	Shroud	1		
02	WG9719530116	Inletwater pipe	1		
03	WG9719530208	Hose	1		
04	WG9719530123	Outlet air pipe	1		
05	WG9719530228	Hose	1		
06	WG9719530207	Hose connector	1		
07	AZ9719530202	Bracket right for radiator	1		
08	Q33208	II-Type hexagon nut	2		
09	Q150B0825	screw	2		
10	WG9716539001	plate	1		
11	AZ9112530333	Expansion tank	1		
12	190003989300	Clip	6		
13	WG9719530261	Expansion tank assy. pipe	2		
14	190003989340	Clip	6		
15	WG9625530003	Sealing cap	2		
16	AZ9725530160	Right puller plate of radiator	1		
17	AZ9716530521	Bracket	1		
18	190003990037	Clip	1		
19	WG9719530212	Outlet water pipe	1		
20	WG9725538235	Rubber Pipe	1		
21	AZ9003980010	Hose clamp	2		
22	WG9719530227	Hose	1		
23	WG9925530022	Clip	2		
24	WG9730530011	Air inlet rubber pipe of inter-cooler	1		
25	Q40116	Washer	1		
26	Q150B1635	Screw	1		
27	Q32016	Hexagon flange nut	1		
28	WG9725530155	Pipe	1		
29	AZ9725530159	Left drawing plate of radiator	1		
30	WG9725530157	Inter-cooler air inlet hose	1		


				STANDARD	2-8-01
冷却系统/Cooling System				PERS	2-048
REP	NUM_ART	DESC	QTY		
31	WG9003980060	Clip	4		
32	WG9725530151	Rubber block	2		
33	AZ9725530152	hose	2		
34	Q40110	Flat washer	2		
35	Q150B1030	Hexagon head bolt	2		
36	Q33210	II-type all-metal hexagon locking nut	8		
37	Q40010	Washer	8		
38	WG9719530272	Cushion pad of HOWO water tank	2		
39	Q40308	Spring washer	8		
40	Q150B0816	Hexagon head bolt	8		
41	AZ9719530201	Bracket left for radiator	1		


		STANDARD		2-9-01
排气系统/Exhaust System		PERS		2-049
REP	NUM_ART	DESC	QTY	
01	WG9725545060	Muffler ass.	1	
02	WG9719540008	Rod	2	
03	Q340B08	nut	4	
04	Q40308	Spring washer	4	
05	Q40108	Washer	4	
06	WG9725540198	Exhaust pipe	1	
07	Q150B1065Q	Screw	3	
08	WG9719540019	Gasket	3	
09	WG9725540163	Hose clip	3	
10	Q33210	Nut	3	
11	WG9725542041	Exhaust pipe ass.	1	
12	WG9725540038	Heat insulation plate	1	
13	WG9731540079	Gasket	1	
14	Q40108	Washer	2	
15	Q40308	Spring washer	2	
16	Q150B0815	Screw	2	
17	Q33212	Nut	4	
18	Q150B1645	Screw	2	
19	Q33216	Nut	4	
20	Q150B1685	Screw	1	
21	Q40116	Washer	2	
22	Q150B1670	Screw	1	
23	Q40110	Washer	6	
24	Q40310	Spring washer	4	
25	Q150B1035	Screw	2	
26	WG9725540310	rod	1	
27	Q150B1020	Screw	2	
28	Q40110	Washer	10	
29	Q33210	Nut	2	
30	Q150B1025	Screw	10	


		STANDARD		2-9-01
排气系统/Exhaust System		PERS		2-050
REP	NUM_ART	DESC	QTY	
31	Q33210	Nut	10	
32	Q33210	Nut	4	
33	Q40110	Washer	4	
34	AZ9719540133	Strap	2	
35	AZ9719540135	Heat insulation plate	1	
36	WG9725540078	pipe	1	
37	WG9725540311	rod	1	
38	AZ9719540290	Bracket	1	
39	Q40310	Spring washer	3	
40	WG9725540057	Gasket	1	
41	Q40110	Washer	8	
42	Q150B1045	Screw	4	
43	WG9725540312	plate	1	
44	WG9725540309	Exhaust Pipe	1	
45	AZ9719540002	Bracket	1	
46	AZ9719540003	Bracket	1	
47	AZ9719540007	plate	2	
48	Q40106	Washer	9	
49	Q150B0610	Screw	9	
50	WG9719540017	Heat insulation plate	1	
51	WG9719540025	Plate	1	
52	Q40306	Spring washer	4	
53	Q150B0620	Screw	4	





		STANDARD	2-9-02
进气系统(油浴式空滤器)		PERS	2-051
REP	NUM_ART	DESC	QTY
02	WG9719190002	空滤器支架总成	1
04	Q150B1235	六角头螺栓	4
05	Q33212	2型全金属六角锁紧螺母	4
06	WG9719190001	空滤器总成	1
08	WG1200190040	干式空滤器堵塞指示器开关	1
10	WG9100770028	保护罩	1
11	WG9100190026	紧固带总成	1
13	199100190065	加强板	1
14	1280 550027	内螺纹销	1
15	1280 550028	内螺纹销	1
16	1280 550029	拉紧螺栓	1
17	WG9719190008	出气软管	1
19	AZ9003980025	软管卡箍, 145/185 N05074	2
20	WG9725190161	双筒式旋风管进气道总成	1
23	AZ9725190133	进气软管	1
24	AZ9003980026	软管卡箍-180/230 N05074	2
25	WG9725190150	油浴式空气滤清器总成	1
27	WG9725190146	油滤器支架总成(6×4/铁壳)	1
29	WG9725190151	拉带总成	1
31	Q150B1450	六角头螺栓	2
32	Q33214	2型全金属六角锁紧螺母	2
33	1113 010043	隔套	3
34	Q150B1030	六角头螺栓	2
35	Q150B1035	六角头螺栓	1
36	Q40310	弹簧垫圈	3
37	Q150B0825	六角头螺栓	2
38	Q40108	平垫圈	2
39	Q33008	全金属六角法兰面锁紧螺母	2
40	Q150B0816	六角头螺栓	2
41	Q40108	平垫圈	2
42	Q40308	弹簧垫圈	2




				STANDARD	3-1-01
DETAIL OF CLUTCH				PERS	3-001
REP	NUM_ART	DESC	QTY		
00	WG9114160010	Clutch Assy	1		
01	WG9114160030	Clutch Bearing	1		
02	WG9114160011	Clutch Plate	1		
03	WG9114160020	Clutch Disc	1		


				STANDARD	3-2-01
Clutch Control Components (Pull-type) (AC22100000501)				PERS	3-002
REP	NUM_ART	DESC	QTY		
01	AZ2220000501	Clutch Housing	1		
02	AZ2229003030	Composite Bush	1		
03	AZ9003073001	Framework Oilseal	1		
04	AZ2229000011	Plug	1		


				STANDARD	3-2-02
Main Housing Components (AC22100100501)				PERS	3-003
REP	NUM_ART	DESC	QTY		
01	AZ2229010013	Shift Rocker Arm Shaft Cover Plate	1		
02	Q1420816	Hexagon Bolt and Spring Washer C	2		
03	AZ2220010506	Main Housing	1		
04	AZ2229010009	Plate	1		
05	Q1420816	Hexagon Bolt and Spring Washer C	3		
06	AZ2229010002	Plug	2		
07	AZ2212010001	Interlock Shaft—Main Housing and	1		
08	AZ2229010012	Lock Spring	2		
09	AZ2229010008	Interlock Spring Seat	1		
10	AZ2222010002	Oil Cooler Cover	1		
11	Q1461035	Bolt Components	4		
12	AZ2229010001	Locating Pin	4		
13	AZ2229010010	lock screw	1		
14	AZ2222010001	Idle Gear Cover	1		
15	Q1421025	Hexagon Bolt and Spring Washer C	8		
16	AZ2203010017	Drain Plug Assembly	1		
17	AZ2229010011	Lock Pin	1		
18	AZ2229010005	Damping Spring Seat	1		
19	Q1421040	Hexagon Bolt and Spring Washer C	23		

				STANDARD		3-2-03	
Input Shaft and Cover Assy.(Pull Type) (AC22100200501)				PERS		3-004	
REP	NUM_ART	DESC	QTY				
01	AZ9003801032	Hexagon Bolt and Spring WasherC	10				
02	AZ2222020020	Bearing Cover	1				
03	AZ9003070501	Oil Seal	1				
04	Q43175	Circlip for Shaft	1				
05	AZ9003323131	Taper Baring	1				
06	AZ2210020501	Input Shaft	1				
07	AZ2229020020	Lock Ring	1				
08	AZ2210020502	3rd/4th Cone Ring	1				


				STANDARD	3-2-04
Range Shaft Components (AC22100300501)				PERS	3-005
REP	NUM_ART	DESC	QTY		
1-5	AZ2203030501	Range Shaft Assy.	1		
01	AZ9003323212	Bearing	2		
06	AZ2208030001	Rear Bearing Adjusting Shim Group	nb		

				STANDARD	3-2-05
Mainshaft Components (AC22100400503)				PERS	3-006
REP	NUM_ART	DESC	QTY		
01	AZ2229040315	Rear Oil Joint	1		
02	AZ2208040004	Rear Bearing Adjusting Shim Group	1		
03	AZ2229040313	Rear Bearing Snap Ring	1		
04	AZ2208040003	Rear Bearing Adjusting Shim Group	1		
05	AZ2229040316	Seal Ring	1		
06	AZ2229040317	Seal Ring	1		
07	AZ2229040312	Seal— off Bushing	1		
08	AZ9003323221	Rear Taper Roller Bearing	1		
09	AZ2229040309	Reverse Thrust Washer	1		
10	AZ2210040406	Reverse Gear	1		
11	AZ2229020020	Lock Ring	1		
12	AZ2210040711	Reverse Cone Ring	1		
13	AZ9003990424	Needle Bearing	2		
14	AZ2229040306	3rd/R Needle Bearing Race	1		
15	AZ2229040308	1st/2nd Hub Stop Ring	2		
16	AZ2210040734	1st/R Hub Sleeve	1		
17	AZ2210040710	1st/R Hub	1		
18	AZ2229100211	Synchronizer Spring	3		
19	AZ2229040301	Synchronizer Key	3		
20	AZ2229040326	Synchronizer Key Seat	3		
21	AZ2203040451	1st/2nd Synchronizing Ring Assy.	1		
22	AZ2210040742	1st/2nd Cone Ring	1		
23	AZ2210040405	1st Gear	1		
24	AZ9003990428	Needle Baring	2		
25	AZ2210040401	Mainshaft	1		
26	AZ9003990428	Needle Bearing	2		
27	AZ2210040404	2nd Gear	1		
28	AZ2210040742	1st/2nd Cone Ring	1		
29	AZ2203040451	1st/2nd Synchronizing Ring Assy.	1		
30	AZ2210040737	2nd/3rd Hub Sleeve	1		


				STANDARD	3-2-05
Mainshaft Components (AC22100400503)				PERS	3-007
REP	NUM_ART	DESC	QTY		
31	AZ2203040452	2nd/3rd Hub Assy.	1		
32	AZ2229100211	Synchronizer Spring	3		
33	AZ2229040301	Synchronizer Key	3		
34	AZ2229040327	Synchronizer Key Seat	3		
35	AZ2229040306	3rd/R Needle Bearing Race	1		
36	AZ9003990424	Needle Bearing	2		
37	AZ2203040451	1st/2nd Synchronizing Ring Assy.	1		
38	AZ2203040451	1st/2nd Cone Ring	1		
39	AZ2210040403	3rd Gear	1		
40	AZ2229040304	4th Needle Bearing Race	1		
41	AZ9003999725	Needle Bearing	2		
42	AZ2229040305	3rd Thrust Washer	1		
43	AZ2210040402	4th Gear	1		
44	AZ2229020020	Lock Ring	1		
45	AZ2210020502	3rd/4th Cone Ring	1		
46	AZ2210040702	3rd/4th Synchronizer Ring	1		
47	AZ2210040736	4th/5th Hub Sleeve	1		
48	AZ2210040701	4th/5th Hub	1		
49	AZ2229040307	Synchronizer Spring	3		
50	AZ2229040301	Synchronizer Key	3		
51	AZ2229040326	Synchronizer Key seat	3		
52	AZ2210040702	3rd/4th Synchronizer Ring	1		
53	AZ2210020502	3rd/4th Synchronizing Cone Ring	1		
54	AZ2229020020	Lock Ring	1		
55	AZ2229040310	Washer and Lock Cap	1		
56	AZ2229040311	Lock Nut	1		
57	AZ9003324395	Front bearing	1		
58	AZ2229040314	Front Oil Joint	1		
59	AZ2203040503	Mainshaft Assy	1		


				STANDARD	3-2-06
Idler Shaft Assy. (AC22100500501)				PERS	3-008
REP	NUM_ART	DESC	QTY		
01	AZ2229050003	Thrust Ring	2		
02	AZ9003997003	Thrust Needle Bearing	2		
03	AZ2210050002	Idler Gear	1		
04	AZ2212050003	Idler Shaft	1		
05	AZ9003995249	Needle Bearing	2		


				STANDARD		3-2-07	
HIGH/LOW Range Assy. (AC22101000501				PERS		3-009	
REP	NUM_ART	DESC	QTY				
00	AZ2203100206	Hi/Lo Assy	1				
01-13	AZ2203100105	Planetary Carrier Assy.	1				
14	AZ2229100201	Retainer Ring	1				
15	AZ9003991113	Thrust Bearing	2				
16	AZ2210100005	Ring Gear	1				
17	AZ2210100021	Ring Gear Seat	1				
18	AZ2229100012	Round Wire Snap Ring	1				
19	Q1401235	Hex Bolt and Washer Components	9				
20	AZ2229100002	Bush—Torque Driving	9				
21	AZ2203100108	Hub Assy., low	1				
22	AZ2203100107	Synchronizer Ring Assy.	2				
23	AZ2210100124	Hub Sleeve	1				
24	AZ2229100211	Synchronizer Spring	3				
25	AZ2229040301	Synchronizer Key	3				
26	AZ2229040327	Synchronizer Key Seat	3				
27	AZ2203100110	Hub Assy.	1				
28	Q433110	Circlip for Shaft	1				
29	AZ2229100203	Planetary Carrier Spacer	1				
30	AZ2229100202	Retainer Ring	1				
31	AZ2210100126	Hub, high	1				
32	Q1421055	Hex bolt and Spring Washer Comp	21				
33	Q1421060	Hex bolt and Spring Washer Comp	2				
34	AZ2229100210	lifting Boss	1				
35	AZ2220100201	Range Housing	1				
36	AZ9003316317	Bearing	1				
37	AZ2208100003	Adjusting Shim Group	nb				
38	AZ2210100050	Speedometer Worm	1				
39	WG9003070105/3	Oil Seal	1				
40	AZ2229100205	Gasket	1				
41	AZ2229100076	Cylinder Seal Ring	2				





				STANDARD	3-2-07
HIGH/LOW Range Assy. (AC22101000501				PERS	3-010
REP	NUM_ART	DESC	QTY		
42	AZ2229100206	Fork Key	2		
43	AZ2229100207	Screw	2		
44	AZ2214100004	Fork	1		
45	AZ2214100005	Fork Shaft	1		
46	AZ9003076900	O Ring 53006900 GB3452.1	1		
47	AZ9003071700	O Ring 26500170 GB3452.1	1		
48	AZ2229100050	Piston	1		
49	AZ9003870016	Hex Nut	1		
50	AZ2229100049	Gasket	1		
51	Q1421065	Hex bolt and Spring Washer Comp	3		
52	Q1421065	Hex bolt and Spring Washer Comp	1		
53	WG2222100009	Cylinder	1		
54~5	WG2209280010	Speedometer Joint Assy.	1		
60	AZ2229100074	Lock Cap	1		
61	AZ2229100073	Bolt	1		
62	AZ2229100072	Cover	1		
63	Q5280514	Pin	1		
64	AZ2210100028	Output Flange	1		
66	Q1421045	Hex bolt and Spring Washer Comp	7		
67	Q170B1045	Hex Bolt with Holes on the Head	1		
67.1	Q40310	Spring Washer	1		
68	AZ2222100052	Bearing Cover	1		
69	AZ2229100208	Plug	1		
70	AZ9004130036	Washer	1		
71	Q150B1216	Hex bolt	4		
71.1	Q40312	Spring Washer	4		
72	AZ2229100047	Cover	1		




			STANDARD		3-2-07
HIGH/LOW Range Assy. (AC22101000501			PERS		3-011
REP	NUM_ART	DESC	QTY		
73	AZ2229100148	Gasket	1		
74	AZ9004130016	Washer	1		
75	Q617B16	Plug	1		
76	Q150B0820	Hex Bolt	1		
77	AZ2229100075	Oil Return Hole Cover	1		
78	AZ9003070800	O Ring 18000800 GB3452.1	1		

				STANDARD	3-2-08
Top Cover and Pneumatic Shift Servo Assy.				PERS	3-012
REP	NUM_ART	DESC	QTY		
01	WG2229210084	Plug	1		
02	WG2229210083	Lock Nut	1		
03	WG2229210082	Washer	1		
04	WG2229210081	Bush	2		
05	WG2214210015	Select Arm	1		
06	WG2229210080	Rubber Sleeve	1		
07	WG9003073045	Oil Seal	1		
08	WG2203210311	Shift Sleeve Assy.	1		
09	WG9003075568	Oil Seal	1		
10	WG2229210077	Bush I	1		
11	WG2229210078	Bush II	1		
12	WG2229210079	Pin	1		
13	WG2229210076	Support Bar Assy.	1		
14	WG2229210075	Select Lever Assy.	1		
15	Q43112	Circlip for Shaft	1		
16	WG2229270003	Select Support Shaft	1		
17	Q150B1090	Hex Bolt	4		
17	Q40310	Spring Washer	4		
18	Q72220	Bowl Shaped Cap	1		
19	AZ2222210025	Housing	1		
19	WG2229210050	Gasket	1		
20	WG2229002520	Composite Bush	1		
21	WG2229210017	Gasket	1		
22	WG2222210026	Cover Seat	1		
23	Q1420825	Hex bolt and Spring Washer Comp	8		
24	Q901	Normally Open Plug	1		
25	WG2229210063	Right Cap	1		
26	AZ2229210032	Gasket	1		
27	WG2212210013	Shift Shaft(double lever)	1		
28	WG2214210012	Shift Finger	1		


				STANDARD	3-2-08
Top Cover and Pneumatic Shift Servo Assy.				PERS	3-013
REP	NUM_ART	DESC	QTY		
29	WG2229210009	Pin	1		
30	AZ2229210036	Guide Sleeve	2		
31	WG2214210011	Interlock Fork	1		
32	AZ2229210008	Scalloped Selflocking Block	1		
33	WG2229210012	Pin	1		
34	WG2229210007	Center Ring	2		
35	WG2229210021	Center Spring (low speed)	1		
36	Q43120	Circlip for Shaft	1		
37	Q5280632	Pin	1		
38	WG2229210061	Sensor Drive Ring	1		
39	WG2229210001	Bush	1		
40	WG9003343178	Needle	1		
41	WG2229210011	Spring Catch	1		
42	WG2229210033	Self lock Spring	1		
43	WG2212210015	Self lock Pin	1		
44	Q72214	Bowl Shaped Cap	1		
45	WG2203210313	Shift Pull Rod Assy.	1		
46	WG2203210312	Select Pull Rod Assy.	1		
47	Q40310	Spring Washer	4		
48	Q341B10	Hex Nut- fine pitch thread	4		
49	WG2203210314	Pneumatic Shift Servo Assy.	1		
50	WG2229210090	Air Pipe Joint	1		
51	WG2229210093	Bracket	1		
52	Q1421025	Hex bolt and Spring Washer Comp	4		
53	AZ9003801026	Fine Pitch Bolt Components	3		


				STANDARD	3-2-09
Fork Shaft Assy. (AC22102200501)				PERS	3-014
REP	NUM_ART	DESC	QTY		
01	AZ2214220016	1st/R Gate	1		
02	AZ2229100207	Fork Tightening Screw	10		
03	AZ2212220006	1st/R Shift Fork Shaft	1		
04	AZ2214220015	1st/R Shift Fork	1		
05	AZ2229100206	Fork Key	6		
06	AZ2212220007	2nd/3rd Fork Shaft	1		
07	AZ2214220019	5th/6th Shift Gate	1		
08	AZ2212220008	4th/5th Fork Shaft	1		
09	AZ2214220018	4th/5th Fork	1		
10	AZ2214220017	2nd/3rd Fork	1		
10	AZ2203220014	1st/R Shift Fork Shaft Assy	1		
10	AZ2203220015	2nd/3rd Fork Shaft Assy	1		
10	AZ2203220016	4th/5th Fork Shaft Assy	1		


			STANDARD		3-2-10	
Oil Pump and Pipeline Assy. (AC22102400501)			PERS		3-015	
REP	NUM_ART	DESC	QTY			
01	AZ2203240019	Oil Pump Assy.	1			
02	Q1421050	Hex bolt and Spring Washer Comp	16			
03	Q41710	Curved Spring Washer	8			
04	AZ9003961055	Hex Socket Bolt	8			
05	AZ9003071618	O Ring14.9X1.9	1			
06	AZ9003072018	O Ring 18.9X1.8	2			
07	AZ2203240018	Oil Spray Pipe Assy.	1			
08	AZ9003071618	O Ring14.9X1.9	1			
09	AZ2203240017	Filter Pipe Assy.	1			
10	WG9003073018	O Ring	1			
11	AZ2229240033	Round Wire Snap Ring	1			
12	AZ2229240032	Sealing Bush	1			
13	AZ2229010007	Gasket	1			
14	AZ2203010008	Filter Assy.	1			
15	Q1421035	Hex bolt and Spring Washer Comp	2			


		STANDARD	3-2-11
Clutch Control Components (double lever,pull type) (AC22102700102)		PERS	3-016


REP	NUM_ART	DESC	QTY
01	Q150B1020	Hex bolt and Spring Washer Comp	4
01	Q40310	Spring Washer	4
02	AZ2229270011	Bracket (pull type)	1




				STANDARD	3-2-12
Clutch Control Mechanism Assy.(AC22102600502)				PERS	3-017
REP	NUM_ART	DESC	QTY		
01	Q1421250	Hex bolt and Spring Washer Comp	3		
02	AZ2229260035	Fork Shaft Bracket	1		
03	AZ2229003030	Composite Bush	1		
04	Q1421030	Hex bolt and Spring Washer Comp	4		
05	AZ2229260015	Cylinder Bracket	1		
06	8X25A	Flat Key (GB/T 1096-79)	2		
07	Q2881016F9	Hex Socket Screw	2		
08	AZ2203260014	Fork Shaft Assy.	1		
09	AZ2214260001	Release Fork	1		
10	AZ2229260037	Cover	1		
11	Q1420612	Hex bolt and Spring Washer Comp	4		

				STANDARD	3-2-13
Power Take off				PERS	3-018
REP	NUM_ART	DESC	QTY		
01	AC97002900151	Power Take Off	1		
02	AZ9703290002	Spline Shaft	1		
05	AZ9003326307	Roller Bearing	1		
06	Q43135	Circlip for Shaft	1		
07	AZ9729290001	Thrust Ring	1		
09	AZ9720290001	Front Body	1		
10	Q5220820	Pin	2		
11	AZ9729290002	Gasket	1		
12	Q150B1230	Hex Bolt	1		
13	Q150B1250	Hex Bolt	3		
14	Q40312	Spring Washer	4		
17	AZ9720290002	Rear Body	1		
18	Q61902	Hex Socket Plug	1		
20	AZ9710290001	Input Shaft	1		
23	AZ9003322216	Roller Bearing	1		
24	Q43130	Circlip for Shaft	1		
25	AZ9003990062	Snap Ring	1		
27	AZ9710290003	Output Shaft	1		
30	AZ9003322206	Roller Bearing	1		
31	Q43130	Circlip for Shaft	1		
32	AZ9003322208	Roller Bearing	1		
33	AZ9003990086	Snap Ring	1		
34	Q150B1060	Hex Bolt	4		
35	Q150B1032	Hex Bolt	1		
36	Q40310	Spring Washer	5		
39	AZ9722290001	Output Shaft Cover	1		
40	AZ9003070050	Framework Oil Seal	1		
41	AZ9729290003	Gasket	1		
42	Q150B1030	Hex Bolt	2		


				STANDARD	3-2-13
Power Take off				PERS	3-019
REP	NUM_ART	DESC	QTY		
43	Q150B1095	Hex Bolt	2		
44	AZ9003801042	Hex Bolt	2		
45	Q40310	Spring Washer	6		
47	AZ9710290002	Flangeφ100	1		
49	AZ9729290004	Press Plate	1		
50	AZ9003073350	O Ring	1		
51	Q150B1245	Hex Bolt	1		
52	Q40112T16F9	Flat Washer	1		
53	AZ9003071180	O Ring	1		
54	AZ9712290001	Fork Shaft	1		
55	AZ9714290001	Fork	1		
56	AZ9710290004	Sleeve	1		
58	AZ9003900026	Pin	1		
59	AZ9722290002	Cylinder	1		
60	AZ9729290005	Gasket	1		
61	Q150B0860	Hex Bolt	2		
62	Q40308	Spring Washer	2		
63	AZ9729290006	Spacer	1		
64	AZ9729290007	Spring	1		
65	AZ9003072120	O Ring	1		
66	179100710069	Pressure Switch (KOSTAL)	1		
67	Q72314	Seal Washer	1		
68	AZ2229210027	Neutral Sensor Lifting Pin	1		
69	AZ9003392220	Roller Bearing	1		
70	AZ9003070800	O Ring	1		
71	AZ2203240006	Oil Inlet Pipe Assy.	1		
75	190003962607	Hellow Bolt	1		
76	Q72310	Seal Washer	2		

				STANDARD	3-3-01
Pneumatic Control Assy. (constantly aired) (AC22102500502)				PERS	3-023
REP	NUM_ART	DESC	QTY		
01	AZ9003071700	O Ring	1		
02	AZ2229250017	Bush	1		
03	AZ2229250004	Spring	1		
04	AZ2229250015	Lock Pin	1		
05	AZ2229250035	Gasket	1		
06	AZ2203250010	Pneumatic Lock Valve Assy.	1		
07	AZ2229250006	Straight Joint	1		
08	AZ2229250024	Gasket	1		
09	AZ2203250003	Double H Valve	1		
10	190003962621	Hollow Bolt	4		
11	Q72314	Seal Washer	8		
12	AZ2203250045	Hose Assy.(L)	1		
13	AZ2203250046	Hose Assy.(H)	1		
14	Q218B0880	Hex Socket Screw	4		
15	Q40308	Spring Washer	4		

				STANDARD	3-3-02
Switch Assy.(AC22102800201)				PERS	3-024
REP	NUM_ART	DESC	QTY		
01	WG9100710041	Press Switch(normally closed)	1		
01	AZ2209280004	Press Switch(normally closed)	1		
02	WG2229210027	Neutral Sensor Lifting Pin	1		
03	AZ2229280001	Seal Washer	3		
04	WG2229280002	Sensor Lifting Pin	1		
05	Q43708	Round Wire Snap Ring for Shaft	1		
06	WG9100710068	Press Switch(normally opened)	1		
06	AZ2209280003	Press Switch(normally opened)	1		
07	AZ9100710070	Press Switch(normally closed)	1		


		STANDARD	3-3-03
GEAR BOX CROSSMEMBER		PERS	3-025

REP	NUM_ART	DESC	QTY
02	WG9725590319	Bracket	2
06	Q150B1080	Hex Screw	4
07	199100680068	Bushing	2
08	1880 680024	Bracket Cover	2
10	AZ9725590361	Crossmember	1
11	Q33210	Nut	4
12	AZ9725590313	Clamp	2
13	AZ9725590309	Plate	2
15	Q150B1685	Screw	1
16	Q150B16100	Screw	1
17	Q40116	washer	2
18	Q33216	nut	2




		STANDARD	3-3-04
GEAR BOX CONTROL DEVICES		PERS	3-026

REP	NUM_ART	DESC	QTY
01	AZ9700240116	HW19710T管路示意图	1
02	AZ9700240077	防尘罩	1
03	WG9700240026	变速器换挡手柄及挡位标牌总成(10	1
05	WG9700240006	变速器手柄气管	1
07	WG9700240003	6/4快插变径接头	1
09	190003179782	聚酰胺管 (Φ6*1)	30
10	WG9000361316	T型三通接头体3-NW4	1
11	WG9000361316/1	T型三通接头体3-NW4	1
12	190003179782	聚酰胺管 (Φ6*1)	110
13	190003179782	聚酰胺管 (Φ6*1)	120
14	WG9000361001	弹性元件NG6	1
15	WG9000361001/1	弹性元件NG6	1
16	WG9000361002	卡簧NG6	1
17	WG9000361002/1	卡簧NG6	1
18	WG9000361003	螺母座NG6	1
19	WG9000361003/1	螺母座NG6	1
20	WG9000361107	直通接头体NG6/NW4	1
21	WG9000361107/1	直通接头体NG6/NW4	1
22	AZ9700240078	变速器操纵杆	1
23	Q40312	弹簧垫圈	1
24	Q340B12	I 型六角头螺母	1
25	AZ9725240115	操纵器连接块 (右置车)	1
26	Q218B0825	内六角圆柱头螺钉	6
27	Q40008	小垫圈	6
28	WG9725240255	操纵器(右置)	1
30	Q150B0816	六角头螺栓	1
31	Q40308	弹簧垫圈	1
32	Q150B0845	六角头螺栓	2
33	Q150B0830	六角头螺栓	2
34	Q40308	弹簧垫圈	4
35	AZ9725240119	纸垫	2




		STANDARD	3-3-04
GEAR BOX CONTROL DEVICES		PERS	3-027

REP	NUM_ART	DESC	QTY
36	WG9725240224	换挡软轴总成 (4100)	1
37	WG9725240224/1	换挡软轴总成 (红色/细/4100/上海莫尔其)	1
38	WG9725240225/1	换挡软轴 (红色/细/4100/上海莫尔其)	1
39	WG9725240246	换挡软轴总成 (4000)	1
40	WG9725240246/1	换挡软轴总成 (黑红色/4000/上海莫尔其)	1
41	WG9725240247/1	换挡软轴 (黑红色/4000/上海莫尔其)	1
46	AZ9718360017	六角头螺栓	1
47	Q150B1035	平垫圈	1
48	Q40210	弹簧垫圈	1
49	Q340B10	I型六角螺母	1
50	Q40310	五孔支架	1
51	199012360441	六角头螺栓	1
52	Q150B0835	大垫圈	1
53	Q40208	六角螺母	1
54	Q340B08	弹簧垫圈	1
55	Q40108	角形支架	1
56	Q40308	六角头螺栓	1




				STANDARD	4-1-01
FRONT AXLE				PERS	4-001
REP	NUM_ART	DESC	QTY		
01	AZ9719410083	大垫圈	1		
01	AZ9125411154	1型六角螺母	1		
01	AZ9925410121	平垫圈	1		
01	AZ9719410093	弹簧垫圈	1		
02	WG880 410031	Knuckle pin	2		
03	AZ9112410055	Left knuckle	1		
03	AZ9112410056	Right knuckle	1		
04	WG880 410060	Stud	2		
05	WG9100410129	Bushing	2		
06	AZ9719410005	Steering knuckle Arm	1		
07	190003888626	Nut fastener	2		
08	WG9700410049	Bearing	2		
09	AZ9719410041	Tie Rod Arm (left)	1		
10	AZ9719410040	Tie Rod Arm(right)	1		
11	WG880 410038	Brake shoe pin	4		
12	190003872377	Castle Nut	4		
13	Q5005050	Cotter pin	4		
14	AZ9100410032	Bracket (left)	1		
15	AZ9100410036	Bracket (right)	1		
16	WG9100410035	Bushing	2		
17	WG9100340017	Complex bushing	4		
18	1880 410094	Shim	nB		
18	1880 410095	Shim	nB		
18	1880 410096	Shim	nB		
18	1880 410097	Shim	nB		
18	1880 410104	Shim	nB		
18	1880 410105	Shim	nB		
18	1880 410106	Shim	nB		
18	1880 410107	Shim	nB		
18	1880 410108	Shim	nB		

		STANDARD	4-1-01
FRONT AXLE		PERS	4-002
REP	NUM_ART	DESC	QTY
19	WG880410052	"O" ring	2
20	WG880 410075	Stud	8
21	190003888458	Nut	8
22	AZ9003963004	Grease fitting	2
23	WG880 410059	Adjusting bolt	2
24	Q351B14T15	Nut	2
25	WG9112410009	Front hub	2
26	WG880 410100	Cap	2
27	Q43056	Spacers	2
28	WG9100410104	Wheel bolt	20
29	WG9003884160	Nut	20
30	Q150B0816	Cap screw	16
31	Q40308	Spring shim	16
32	190003326543	Bearing	2
33	190003326531	Bearing	2
34	WG99000410114	Spacers	2
35	WG9003074387	Seal	2
36	Q5211016	Pin	2
37	WG9100410062	Washer	2
38	AZ9100411140	Knuckle lock nut	2
39	Q5006370	Cotter pin	2
40	Q151C1220	Cap screw	4
41	WG9100410043	Cap	2
42	WG9100410060	Egis Cover	2
43	WG2297Y4835	Plaque	1
44	WG9112410019	Annulus ring	2





		STANDARD		4-1-02
转向装置/Steering System		PERS		4-001
REP	NUM_ART	DESC	QTY	
0	AZ9719471050	Steering tube assembly	1	
1	WG9719470100	Steering wheel	1	
1a	WG9130583018	Ring	1	
2	AZ9719470053	Steering shaft	1	
3	Q351B22T15	Nut	1	
4	Q41822	Spring washer	1	
6	Q43125	Snap ring	1	
7	AZ9003320012	Ball bearing	1	
8	WG9130583024	Touch ring	1	
9	WG9130583019	Start switch	1	
10	Q150B0530	Screw	2	
11	Q340B05	Nut	2	
12	81.95801.0071	Roller	2	
13	81.46433.0005	Clip	1	
14	AZ9719470051	Sleeve	1	
15	AZ9123470129	Spring	1	
16	AZ9123470130	Washer	1	
17	AZ9719470424	Support seat	1	
18	Q150B0865	Screw	2	
19	AZ9719471041	Rear cover of steering column	1	
20	Q2720412	Screw	4	
21	AZ9719470057	Limit screw	1	
22	Q40316	Spring washer	1	
23	AZ9719470058	Plate	1	
24	AZ9719470055	Adjusting screw	1	
25	AZ9123470153	Spring	1	
26	AZ9719470052	Bracket for wireness	1	
27	Q150B0408	Screw	2	
28	Q40304	Spring washer	2	
29	Q40104	Washer	2	



		STANDARD	4-1-02
转向装置/Steering System		PERS	4-002


REP	NUM_ART	DESC	QTY
30	AZ9719471042	Front cover of steering column	1
31	Q2714250	Screw	2
32	AZ9123470150	Hand wheel	1
33	AZ9123470155	Washer	1
34	AZ9719470054	Guiding sleeve	1
35	AZ9719470056	Support seat	1
36	Q150B0620	Screw	4
37	Q33208	Nut	4
40	AZ9003320013	Ball bearing	1
41	Q43130	Snap ring	1
42	81.91710.0459	Ring	1
43	Q43042	Snap ring	1
44	AZ9719470043	Universal joint	1
45	AZ9719470044	Telescopic shaft	1
47	Q33206	Nut	4
50	AZ9716470045	Sleeve	1
51	AZ9719470046	Plate	2
52	AZ9100470410	Bush	1




			STANDARD		4-1-03
6×4液压动力转向系统/6×4Hydraulic Steering System			PERS		4-001
REP	NUM_ART	DESC	QTY		
1	WG9716470020	Drop arm	1		
2	Q151B2045TF2	Screw	5		
3	WG9716470150	Steering gearbox	1		
4	AZ9718470070	Connector	1		
5	WG9725470818	Screw	1		
6	T071800	Gasket	2		
7	AZ9716470040	Oil pipe - intake	1		
8	T071800	Gasket	2		
9	Q81714	Connector	1		
10	Q81818	Screw	1		
11	190003559515	Nut	3		
12	Q80014	Cutting sleeve	2		
13	AZ9725478035	Oil pipe - return	1		
16	Q340B06	Nut	5		
17	Q40206	Washer	4		
18	Q40306	Spring washer	5		
21	Q150B0635	Screw	5		
23A	131100040007	Clip	2		
23B	138091360181	Clip	3		
25	AZ9725477020	Bracket	1		
26	AZ9725470238	Bracket	1		
27	190003888627	Nut	6		
28	Q151B1645TF2	Screw	6		
29	17017470015	Spring protect sleeve	2		
30	AZ9123470070	Hose - oil return	1		
31	190003989336	Hose clip	2		
32	AZ9725470084	Spring protect sleeve	1		
33	Q150B1030	Screw	4		
34	Q33210	Nut	4		
35	Q40112	Washer	3		


		STANDARD	4-1-03
6×4液压动力转向系统/6×4Hydraulic Steering System		PERS	4-002


REP	NUM_ART	DESC	QTY
36	Q150B1020	Screw	2
37	Q33210	Nut	4
39	AZ9100470040	Bracket	1
40	WG9719470033	Oil tank	1
41	WG9725470120	Hose	1
42	190003989301	Hose clip	2
43	WG9719470037	Hydraulic pump	1
45	WG9725470110	Connector	1
46	WG9100470076	Connector	1
47	190003098031	Washer	2
48	190003962651	Female screw	1
49	T071800	Gasket	4
50	AZ9716470107	Hose (high pressure)	1
51	Q340B08	Nut	1
52	Q40208	Washer	1
53	Q150B0830	Screw	1
54	Q40308	Spring washer	2
55	Q33210	Nut	2
56	Q150B0835	Screw	1
57	Q33208	Nut	1



				STANDARD	4-1-04
FRONT AXLE TRACK ROD				PERS	4-001
REP	NUM_ART	DESC	QTY		
01	AZ9700430050	Steering Rod	1		


				STANDARD	4-1-04
DRAG LINK				PERS	4-002
REP	NUM_ART	DESC	QTY		
01	AZ9719430010	Drag Link	1		




				STANDARD	4-1-05
FRONT BRAKE, DRUM, CAMSHAFT				PERS	4-001
REP	NUM_ART	DESC	QTY		
01	AZ9112440001	Brake drum	2		
02	Q2541025	Bolt	4		
03	WG9112440006	Dust shield	2		
04	Q150B0816	Screw	8		
05	Q40308	Shim	8		
06	AZ9100440018	Brake shoe	4		
07	WG9100440029	"T" brake lining	4		
07a	WG9100440027	"T" brake lining	4		
08	WG9231340068	Rivet	56		
09	WG880440006	Bushing	4		
10	WG880440008	Washer	2		
11	190003872369	Castle nut	4		
12	Q5005045	Cotter pin	4		
13	AZ9100440061	Return spring	2		
14	WG1218G85	Return spring pin	4		
19	199100440001	Camshaft(left)	1		
20	199100440002	Camshaft(right)	1		
21	WG880410010	Washer	4		
21	AZ9100440011	Washer	4		
21	AZ9100440012	Washer	4		
22	1880 340023	"O" seal ring	4		
23	WG9100440023	Automatic rod adjuster	2		
23a	AZ9100349994	Bracket	1		
23b	AZ9100349995	Bracket	1		
23c	Q150B0818	Screw	2		
23d	Q33408	Nut	2		
24	WG880340022	Shim	2		
25	WG80 320028	Shim	nB		
25	WG80 320029	Shim	nB		
25	WG80 320030	Shim	nB		


		STANDARD	4-1-05
FRONT BRAKE, DRUM, CAMSHAFT		PERS	4-002


REP	NUM_ART	DESC	QTY
25	WG80 320046	Shim	nB
26	190003933116	Washer	2
27	WG9000360100	Diaphragm cyl. left	1
27a	WG9000360101	Diaphragm cyl. Right	1
28	Q41216	Shim	4
29	Q340B16	Nut	4
30	Q40114	Flat shim	2
31	Q5101440	Pin	2
32	Q5004022	Cotter	2
33	1880 440015	Spacers	2
34	1880 340037	Plug	4
59	WG9100440021	Roller	4




				STANDARD	4-1-06
WHEEL COVER				PERS	4-001
REP	NUM_ART	DESC	QTY		
01	AZ9112610090	Cover	2		


				STANDARD	4-1-06
TYRE AND RIM				PERS	4-002
REP	NUM_ART	DESC	QTY		
04	AZ9112610083	Nut Cover	20		



				STANDARD	4-2-01
MIDDLE AXLE HOUSING				PERS	4-010
REP	NUM_ART	DESC	QTY		
01	AZ9231330588	Middle Axle Housing	1		
02	Q5211016	园柱销	1		
03	190003962021	锥螺纹内六角螺塞	1		
04	WG9231330015	磁性螺塞总成	1		
05	Q72336	密封垫圈--Q72336铝L1M,GB3190	1		
06	190003989290	碗形堵塞	1		
07	WG9231330105	通气塞	1		
08	WG9231330106	橡胶软管	1		
09	WG9014330146	弓形固定卡总成(下)	1		
10	WG9014330147	弓形固定卡总成(上)	1		
11	Q2540820	十字槽沉头螺钉	4		
12	190003810631	双头螺柱	4		
13	190003888457	自锁螺母	16		
14	WG2297Y4835	铭牌	1		
15	190003904529	标牌铆钉	2		
16	WG9014330126	操纵杆总成	1		
17	1680M 320015	O型垫圈	1		
18	WG69000330008	销	1		
19	WG69000330009	销	1		
20	WG9100330010	销	1		
21	Q43705	轴用钢丝挡圈	1		
22	Q1200850F3	双头螺柱	1		
23	WG61000060084	间隔衬套	1		
24	Q40108	平垫圈	1		
25	Q33208	2型全金属六角锁紧螺母	1		
26	WG9231340042	气室支架(中桥)	1		
27	Q151B2035TF2	六角头螺栓	1		


		STANDARD		4-2-02
DETAIL OF MIDDLE AXLE		PERS		4-011
REP	NUM_ART	DESC	QTY	
01	WG9014320120	Housing for 1st rear axle driver	1	
02	AZ9231320272	Diff.housing	1	
03	AZ9231320150	Diff.spider	1	
04	WG9231320151	Bevel pinion	2	
05	WG9231320152	Planet Pinion	4	
06	WG9231320153	Intermed.sheet	4	
07	AZ9231320154~158	Shim	按需	
08	WG9231320159	Bush	4	
09	WG9231320160	Bush collar	4	
10	WG9114320251	Pinion and crown wheel	1	
11	Q151B1635TF2	Screw	16	
12	WG9114320003	Locking sheet	1	
13	WG9231320169	Screw	8	
14	190003326148	Roller bearing	2	
15	WG3809320159	Screw ring	2	
16	WG79000320027	Safety clip	2	
17	Q150B0816	Screw	2	
18	Q40308	Spring washer	2	
19	AZ9231320259	Housing	1	
20	AZ9231320264	Housing cap	1	
21	WG9014320118	Cover	1	
22	WG9014320175	Cover	1	
23	190003813628	Stud	14	
24	Q1201225F3	Stud	4	
25	Q1201028F3	Stud	18	
26	Q150B1025	Screw	8	
27	Q150B1020Q	Screw	8	
28	Q340B12	Nut	18	
29	Q340B10	Nut	18	
30	Q40312	Spring washer	18	

		STANDARD	4-2-02
DETAIL OF MIDDLE AXLE		PERS	4-012
REP	NUM_ART	DESC	QTY
31	Q40310	Spring washer	34
32	Q5211016	Pin	4
33	WG9014320208	Driving cylindrical gear	1
34	WG9014320209	Driven cylindrical gear	1
35	WG9014320257	Bearing	1
36	WG9014320256	Wire ring	1
37	190003326333	Bearing	2
38	190003311543	Bearing	2
39	190003310239	Bearing	1
40	199014320174	Washer	1
41	WG9014320140	Spacing collar	1
42	WG9014320129	Bearing block	1
43	WG9014320128	Binder plate	1
44	WG9014320131~134	Shim	按需
45	WG780 320088	Binder plate	1
46	WG9114320002	Locking sheet	1
47	Q150B1430TF2	Screw	3
48	190003813543	Stud	8
49	Q33210	Nut	8
50	WG9014320135	Hollow shaft	1
51	WG9012250031	Nut	1
52	Q433130	Flat wire circlip for shaft	2
53	190003933580	Circlip for shaft	1
54	AZ9231320271	Diff.housing	1
55	WG9231320226	Rear diff. side gear	1
56	WG9231320225	Front diff. side gear	1
57	WG9231320227	Planet Pinion	4
58	AZ9231320223	Diff.spider	1
59	WG9231320224	Intermed.sheet	4
60	WG9231320221	Bush	4




		STANDARD	4-2-02
DETAIL OF MIDDLE AXLE		PERS	4-013

REP	NUM_ART	DESC	QTY
61	WG9231320222	Bush collar	4
62	AZ9231320091~95	Shim	按需
63	AZ9231320096~100	Shim	按需
64	Q151C1280TF2	Screw	12
65	WG9014320061	Shim	1
66	AZ9128320014	φ180 flange 8t	1
66	AZ9231320014	φ180 flange 46t	1
67	WG79000320013	Nut	1
68	Q5005055	Split pin	1
69	WG81500010163	Plug	1
70	1586 33 15	Magnet plug	2
71	Q72336	Seal ring	3
72	WG288 320105	Diff.locking ring	1
73	WG288 320106	Diff.pin	10
74	WG9014320053	Shifting fork	1
75	WG1800 320077	Tappet	2
76	WG9014320076	Diff.arm	1
77	WG2700 320037	Bush	1
78	AZ9231320038	"O" ring	1
79	WG288 730062	"O" seal ring	1
80	190003933072	Circlip for shaft	1
81	190003902070	Screw	1
82	Q340B08	Nut	1
83	Q150B1050Q	Screw	1
84	Q340B10	Nut	1
85	WG69000330008	Pin	1
86	Q43705	Circlip for shaft	1
87	AZ9231320262	Bracket	1
88	Q150B0818	Screw	2
89	Q40308	Spring washer	2
90	WG61000060072	Spacing collar	1





		STANDARD	4-2-02
DETAIL OF MIDDLE AXLE		PERS	4-014


REP	NUM_ART	DESC	QTY
91	Q40108	Plain washer	1
92	Q33208	Nut	1
93	190003070026	Seal ring	1
94	190003078772	Seal ring	1
95	AZ9231320261	Transfixion shaft	1
96	WG9231320205	φ160 flange	1
97	WG9231320141	Bearing block	1
98	WG79000320013	Nut	1
99	Q5005055	Split pin	1
100	WG9231326212	Bearing	1
101	Q150B1030	Screw	6
102	Q40310	Spring washer	6
103	WG9012320014	Shifting fork	1
104	Q2800825	Grub screw	1
105	Q340B08	Nut	1
106	WG1800 320077	Tappet	2
107	WG3809320156	Gear shift sleeve	1
108	WG9231320023	Lashing	1
109	WG3809320155	Shifting dog	1
110	WG3809320158	Locking sheet	1
111	WG3809320157	Nut	1
112	190003070026	Seal ring	1
113	190003078772	Seal ring	1
114	WG2297Y4835	Nameplate	1
115	190003904529	Rivet	2




		STANDARD		4-3-01
REAR AXLE HOUSING		PERS		4-015
REP	NUM_ART	DESC	QTY	
01	AZ9231330569	后桥壳总成	1	
02	Q5211016	园柱销	1	
03	WG81500010163	螺塞	1	
04	WG9231330015	磁性螺塞总成	1	
05	Q72336	密封垫圈	2	
06	190003989290	碗形堵塞	1	
07	WG9231330105	通气塞	1	
08	WG9231330106	橡胶软管	1	
09	WG9014330146	弓形固定卡总成(下)	1	
10	WG9014330147	弓形固定卡总成(上)	1	
11	Q2540820	十字槽沉头螺钉	4	
12	190003810631	双头螺柱	4	
13	190003888457	自锁螺母	16	
14	WG2297Y4835	铭牌	1	
15	190003904529	标牌铆钉	2	
16	WG9014330125	操纵杆总成	1	
17	1680M 320015	O型垫圈	1	
18	WG69000330008	销	1	
19	WG69000330009	销	1	
20	WG9100330010	销	1	
21	Q43705	轴用钢丝挡圈	1	
22	Q1200850F3	双头螺柱	1	
23	WG61000060084	间隔衬套	1	
24	Q40108	平垫圈	1	
25	Q33208	2型全金属六角锁紧螺母	1	
26	WG9231340041	气室支架（后桥）	1	
27	Q151B2040TF2	六角头螺栓	4	

				STANDARD	4-3-02
DETAIL OF REAR AXLE				PERS	4-016
REP	NUM_ART	DESC	QTY		
01	199012320098	Houseing of rear axle driver	1		
02	WG9012320131	Bearing housing	1		
03	WG9012320173-176	Shim	1		
04	Q150B1230TF2	Screw	12		
05	WG9012320133	Gasket	1		
06	AZ9231320274	Diff.housing	1		
07	190003326148	Roller bearing	2		
08	AZ9231320150	Diff.spider	1		
09	WG9231320151	Bevel pinion	2		
10	WG9231320152	Planet Pinion	4		
11	WG9231320153	Intermed.sheet	4		
12	AZ9231320154-158	Shim	1		
13	WG9231320169	Screw	8		
14	WG3809320159	Screw ring	2		
15	WG79000320027	Safety clip	2		
16	Q150B0816	Screw	2		
17	Q40308	Spring washer	2		
18	WG9231320912	Pinion and crown wheel	1		
19	Q151B1635TF2	Screw	16		
20	WG9114320003	Locking sheet	1		
21	190003326546	Roller bearing	1		
22	190003326236	Roller bearing	1		
23	WG880 320002-15	Shim	1		
24	WG9231320110	φ165 flange 46t	1		
25	WG79000320013	Nut	1		
26	Q5005055	Split pin	1		
27	WG9231320001	Gasket	1		
28	WG3809320155	Shifting dog	1		
29	WG3809320158	Locking sheet	1		
30	WG3809320157	Nut	1		

				STANDARD	4-3-02
DETAIL OF REAR AXLE				PERS	4-017
REP	NUM_ART	DESC	QTY		
31	WG9012320014	Shifting fork	1		
32	Q2800825	Grub screw	1		
33	Q340B08	Nut	1		
34	WG1800 320077	Tappet	2		
35	WG3809320156	Gear shift sleeve	1		
36	WG9231320023	Lashing	1		
37	WG2297Y4835	Nameplate	1		


				STANDARD	4-3-03
AXLE BRAKE, DRUM, HUB				PERS	4-018
REP	NUM_ART	DESC	QTY		
01	Q150B1018	Screw	20		
02	WG9231340002	Screw	4		
03	WG9231340001	Cover	2		
04	WG9012340011	Bolt	2		
05	199112340029	Planetary carrier	2		
06	Q2541025	Screw	8		
07	190003330148	Ball	10		
08	WG9012340004	Bolt	10		
09	WG99-934-013	Needle	20		
10	WG9012340075	Washer	10		
11	WG9012340077	Washer	10		
12	WG9012340122	Planet gear	10		
13	190003933351	Circlip	2		
14	WG880 410097	Washer	2		
15	WG9012340005	Sun gear	2		
16	WG9012340076	Washer	2		
17	WG9003884160	Nut	20		
18	WG880420027	Oil drip pan	2		
19	Q151C1295TF2	Screw	10		
20	190003901704	Cyl.pin	10		
21	WG9231340223	Drive axle left	1		
21	WG9231340224	Drive axle right	1		
22	WG680340016~19.186.	Shim	按需		
23	WG680340015	Securing sheet	2		
24	WG880420034	Securing ring	2		
25	WG9112340021	Support for intermed.ring gear	2		
26	WG9012340121	Intermed.ring gear	2		
27	WG880420014	Srap ring	2		
28	190003326167	Roller bearing	2		
29	199012340029	O Ring	4		

				STANDARD	4-3-03
AXLE BRAKE, DRUM, HUB				PERS	4-019
REP	NUM_ART	DESC	QTY		
30	WG9231340909	Rear wheel hub C	2		
31	WG9012340021	Oil drip pan	2		
32	WG9012340020	Gasket	2		
33	Q40308	Spring washer	20		
34	Q150B0816	Screw	20		
35	WG9231340917	Spacer ring	2		
36	WG9981340113	Seal double	2		
37	Ref 36				
38	WG9231342006	Brake drum	2		
39	AZ9231342070	Brake shoe & lining	4		
39.1	WG9231342068	Brake Lining			
39.2	189000340068	Rivet			
40	WG9100340012	Spring	2		
41	199112340049	Spring	4		
42	WG9000340027	Pressure roller	4		
43	WG880440032	Pin	2		
44	199000340064	Brake shoe pin	4		
45	Q5280624	Pin	4		
46	WG9231340226	Brake camshaft Lh	1		
46	WG9231340227	Brake camshaft Rh	1		
47	WG880440010	Shim	4		
48	WG880340023	"O" ring	2		
49	WG9100340017	Bush	4		
50	Q151B1645TF2	Screw	4		
51	AZ9231340556	ABS Bracket	2		
52	Q151B1635TF2	Screw	16		
53	AZ9231340562	Brake anchor	2		
54	190003933300	Circlip	2		
55	AZ9231342008	Brake cover	2		
56	WG880340037	Gasket	8		




		STANDARD	4-3-03
AXLE BRAKE, DRUM, HUB		PERS	4-020


REP	NUM_ART	DESC	QTY
57	Q40308	Spring washer	12
58	Q150B0816	Screw	12
59	WG9112340010	Bush	2
60	190003963112	Grease nipple	2
61	WG880340031~34	Shim	按需
62	199014340041	Bracket	2
63	Q151B1445	Screw	2
64	Q151B1490	Screw	2
65	WG9100340056	Adjuster left	1
66	WG880340022	Washer	1
67	WG80 320028~30.46	Shim	按需
68	190003933116	Circlip	1
69	190003326067	圆锥滚子轴承 30222 GB/T297-94	2
70	WG9012340027	密封圈	2





		STANDARD	4-3-04
Bogie		PERS	4-021


REP	NUM_ART	DESC	QTY
02	AZ9925520310	Balance shaft with housing	2
02.1	AZ9925520233	Bracket	1
02.2	AZ9725520237	Balance shaft	1
02.3	WG9925520235	Balance shaft housing	1
02.4	WG9114520042	Spherical bearing	2
02.5	WG9725520136	Cover	1
02.6	WG614 130062	Sealing ring	1
02.7	WG9925520223	Sealing ring	1
02.24	WG9114520223	Sealing ring	1
02.8	WG9725520238	Spacing bush	1
02.9	WG9014520306	Fix washer	1
02.10	WG9100520008	Fix washer	1
02.11	WG9014520192	Fix washer	1
02.12	WG9014520193	Fix washer	1
02.13	WG9014520194	Fix washer	1
02.14	WG9014520303	Fix washer	1
02.15	WG9114520059	Fix washer	1
02.16	AZ9725520239	Press block	1
02.16	WG9725520239	Press block	1
02.17	Q150B1445TF2	Screw	6
02.18	Q40314	Spring Washer	6
02.19	WG9014520311	Cover	1
02.20	190003962021	Plug	1
02.21	Q150B0820	Screw	8
02.22	Q40308	Spring Washer	8
02.23	Q5211630	Cylinder pin	1





				STANDARD	4-3-05
PROPELLER SHAFT				PERS	4-025
REP	NUM_ART	DESC	QTY	 Diagram illustrating the assembly of the Propeller Shaft (1) with Universal Joints (1.1, 2.1) and Flanges (1.2, 2.2). The assembly includes the Transmission Flange (变速器连接盘), Middle Bridge Input/Output Flanges (中桥输入/输出连接盘), and Rear Bridge Input Flange (后桥输入连接盘). Bolts (5, 6) and a Nut (3) are also shown.	
01	AZ9924312030	Propeller shaft	1		
1.1	AZ9115311060	Universal joint	2		
1.2	AZ9315313635	Flange	2		
02	AZ9114310126	Propeller shaft	1		
2.1	WG6013314080	Universal joint	2		
2.2	26013314062	Flange	2		
03	190003888459	Nut	16		
04	WG9000310049	Bolt	16		
05	Q151B1450TF2	Screw	8		
06	AZ9003888458	Nut	8		


				STANDARD	5-1-01
PEDAL CONTROL DEVICE				PERS	5-001
REP	NUM_ART	DESC	QTY		
00	AZ9725361028	Pedal ass.	1		
01	Q40308	Spring washer	2		
02	Q40108	Washer	2		
03	Q150B0820	Screw	2		
04	AZ9719230231	Spring seat	1		
05	AZ9719230232	Spring	1		
06	Q340B08	Nut	2		
07	Q40308	Spring washer	2		
08	Q150B0845	Screw	1		
09	WG9123360067	Plug	2		
10	AZ9719230021	Plug	1		
11	WG9719360060	Sleeve	2		
12	Q150B0616	Screw	1		
13	Q40106	Washer	1		
14	AZ9719230228	Shaft ass.	1		
15	Q40306	Spring washer	1		
16	Q340B06	Nut	1		
17	AZ9123230226	Rubber cover	1		
18	AZ9719230240	Clutch foot pedal ass.	1		
18.1	AZ9123360113	Foot pedal	1		
18.2	AZ9719230051	Clutch foot pedal arm.	1		
18.3	AZ9719230224	Bracket	1		
18.4	AZ9719230052	Shaft sleeve	1		
18.5	AZ9719230071	Bracket	1		
18.6	AZ9719230022	Plate	1		
19	AZ9719230229	Washer	2		
20	AZ9123230053	Needle bearing	1		
21	AZ9719230222	Push rod	1		
22	Q150B0830	Screw	1		
23	AZ9719230073	Bracket	1		


				STANDARD	5-1-01
PEDAL CONTROL DEVICE				PERS	5-002
REP	NUM_ART	DESC	QTY		
24	Q40306	Spring washer	1		
25	Q40106	Washer	1		
26	Q150B0620	Screw	1		
27	WG9718710005	Clutch switch	1		
28	WG9719230023	Clutch pump and tank ass.	1		
29	AZ9719364050	Bracket	1		
31	WG9719364051	Central spindle	1		
32	WG9719364055	Brake pedal ass.	1		
33	WG9719360060	Sleeve	2		
34	AZ9123230226	Rubber cover	1		
35	WG9719360063	Push rod	1		
36	Q173B0845	Screw	1		
37	Q5002016	Split pin	1		
38	Q341B08	Nut	1		
39	WG9719360062	Shaft	1		
40	Q150B0845	Screw	1		
41	WG9123360067	Plug	1		
42	Q340B08	Nut	1		
43	Q1840616	Screw	1		
44	WG9000360520	Foot Brake Valve	1		
45	Q33208	Nut	4		
46	AZ9725230012	Clutch Control	1		
48	AZ9719230226	Shaft	1		
49	AZ9719230227	Bracket	1		
50	WG9725716002	Brake lamp switch	1		
51	Q150B1030	Screw	1		
52	Q150B1020	Screw	4		
53	Q150B1025	Screw	2		
54	Q340B10	Nut	7		
55	Q40310	Spring washer	7		


				STANDARD	5-1-02
驾驶室制动装置/Brake Device In Cab				PERS	5-004
REP	NUM_ART	DESC	QTY		
02	WG9000360522	Parking brake valve	1		
04	Q150B0616	Screw	2		
05	Q40306	Spring washer	2		
06	WG9000361004	Connector NG8	2		
08	WG9000361005	Clip NG8	2		
10	WG9000361006	Nut seat NG8	2		
12	WG9000361307	"L" connector	2		
16	WG9000361011	Plug	1		
18	WG9000361403	Connector	2		
20	WG9719360018	Sleeve	1		
22	WG9719360019	Plug	5		
24	WG9725360036	Plug	1		
26	WG9000361207	Connector	1		
28	WG9000361107	Connector	3		
30	WG9000361108	Connector	2		
32	WG9000361013	Nut	2		
34	WG9000361032	O-ring	2		
38	190003179782	Plastic pipe	2		
39	190003179781	Plastic pipe	3		
40	190003171390	Fastener	5		

		STANDARD		5-1-03
BRAKE CHAMBER		PERS		5-005
REP	NUM_ART	DESC	QTY	
06	190003903661	Shaft	4	
07	Q40114	Washer	4	
08	Q5004022	Split pin	4	
13	WG9000360600	Brake Chamber Middle Axle	2	
14	WG9000360601	Brake Chamber Rear Axle	2	

		STANDARD		5-1-04
FRONT BRAKE CHAMBER		PERS		5-006
REP	NUM_ART	DESC	QTY	
01	WG9000360100	Spring brake actuator -left	1	
02	Q5004025	Split pin	2	
03	Q40114	Washer	2	
04	Q5101440	Shaft	2	
05	WG9000360101	Spring brake actuator -right	1	

				STANDARD	5-1-05
底盘制动装置/Chassis Brake Device				PERS	5-007
REP	NUM_ART	DESC	QTY	 The diagram illustrates the air brake system layout. Key components include: 1: Air compressor (空压机) 65: Line to air compressor 93, 36, 60, 60: Air reservoirs 103, 97, 42, 105: Additional reservoirs and valves 11: 4-circuit protecting valve 151: Main distribution line Branches to the left: To hand brake valve 21, To hand brake valve 1, To service brake valve 21, To service brake valve 12, To service brake valve 11, To service brake valve 22. Branches to the right: To parking relay valve 4 of rear axle, To parking relay valve 1 of rear axle, To service valve 4, To service valve 1.	
01	WG9000360521	Air dryer	1		
03	AZ9719360014	Bracket	1		
04	Q151C1230	Screw	3		
05	Q40112	Washer	3		
06	Q40312	Spring washer	3		
07	Q150B1025	Screw	3		
08	Q40110	Washer	3		
09	Q40310	Spring washer	3		
10	Q340B10	Nut	3		
11	WG9000360523	4-circuit protecting valve	1		
13	AZ9719360013	Bracket	1		
14	Q150B1020	Screw	2		
15	Q40110	Washer	2		
16	Q40310	Spring washer	2		
17	Q340B10	Nut	2		
18	Q150B0818	Screw	2		
19	Q40308	Spring washer	2		
20	WG9000360703	Air reservoir (40L)	1		
22	AZ9118360004	Support ass.	2		
23	AZ9118360005	Bracket	1		
24	179000360326	Plate	2		
25	WG93 250096	Spacer	4		
27	Q150B1060	Screw	4		
28	WG99118360019	Tension strap	2		
30	Q40110	Washer	6		
31	Q40310	Spring washer	6		
32	Q340B10	Nut	6		
33	Q5101048	Shaft	2		
34	Q40110	Washer	2		
35	Q5003214	Split pin	2		

				STANDARD	5-1-05
底盘制动装置/Chassis Brake Device				PERS	5-008
REP	NUM_ART	DESC	QTY	 The diagram illustrates the chassis brake system layout. It includes two main air reservoirs (36 and 42) connected to a central manifold (103). The system is supplied by an air compressor (65) via a line labeled 'To air compressor'. Various valves are shown, including hand brake valves (21, 1), parking relay valves (4, 1 of rear axle), and service brake valves (21, 12, 11, 22). The system also features an exhaust air resource (105) and a service valve (4). Connections are labeled in Chinese and English, such as 'To hand brake valve 21', 'To parking relay valve 4 of rear axle', and 'To service valve 4'. The diagram includes numerous numbered callouts (1, 11, 20, 21, 36, 42, 60, 65, 68, 87, 89, 91, 93, 95, 97, 103, 105, 11, 151) corresponding to the parts listed in the BOM table.	
36	WG9000360706	Air reservoir (35L)	1		
42	WG9000360705	Air reservoir (30L)	1		
44	AZ9718360005	Support ass.	1		
45	AZ9719360017	Plate	1		
46	AZ9718360003	Bracket	1		
47	AZ9718360004	Plate	1		
48	Q150B0822	Screw	8		
49	Q40108	Washer	8		
50	Q40308	Spring washer	8		
51	Q340B08	Nut	8		
52	WG9719360024	Tension strap	4		
54	WG09 190017	Tension bolt	4		
56	WG700 550013	Tension bolt	4		
59	Q218B0880	Screw	4		
60	WG9000361402	Draining valve	4		
62	190003179781	Plastic pipe	22		
63	190003179785	Plastic pipe	30		
64	AZ9003170002	Plastic pipe	3		
65	AZ9718360029	Tube	1		
66	190003559515	Nut	2		
67	190003559562	Clip	2		
68	AZ9100362002	Connector	1		
69	WG9000361015	Nut	1		
71	WG9000361016	Washer	1		
73	WG9000361017	O-ring	1		
75	WG9000361004	Connector	1		
77	WG9000361005	Snap ring	1		
79	WG9000361006	Nut seat	1		
81	WG9000361007	Connector	13		
83	WG9000361008	Snap ring	13		

				STANDARD	5-1-05
底盘制动装置/Chassis Brake Device				PERS	5-009
REP	NUM_ART	DESC	QTY		
85	WG9000361009	Nut seat	13		
87	WG9000361301	"L" Connector	1		
89	WG9000361401	Connector	1		
91	WG9000361201	Connector	1		
93	WG9000361202	Connector	2		
95	WG9000361203	Connector	2		
97	WG9000361204	Connector	9		
99	WG9000361306	"T" Connector	2		
101	WG9000361106	Connector	2		
103	WG9000361101	Connector	1		
105	WG9000361012	Plug	2		
109	AZ9003179031	Protection sleeve	150		
110	190003179046	Protection sleeve	150		
111	190003179046	Protection sleeve	150		
112	WG17017361000	Protect pipe	2		
114	WG17017361000	Protect pipe	2		
116	WG9123360300	Protection sleeve	900		
118	WG9100360134	Spacer	10		
119	199100360134	Spacer	1		
120	WG9100360135	Spacer	10		
121	199100360135	Spacer	1		
122	190003171390	Fastener	30		
123	190003171392	Fastener	25		
124	190003179030	Plate	39		
125	190003179030	Plate	39		
126	199012360441	Angle bracket	1		
127	Q150B1035	Screw	1		
128	Q40110	Washer	1		
129	Q40310	Spring washer	1		
130	Q340B10	Nut	1		


		STANDARD		5-1-05
底盘制动装置/Chassis Brake Device		PERS		5-010
REP	NUM_ART	DESC	QTY	
131	1185 770036	Clip	1	
132	161000060211	Hose	1	
133	Q150B0620	Screw	1	
134	Q40106	Washer	1	
135	Q40306	Spring washer	1	
136	Q340B06	Nut	1	
137	199100360165	Angle bracket	2	
138	Q150B1225	Screw	2	
139	Q40112	Washer	2	
140	Q40312	Spring washer	2	
141	Q340B12	Nut	2	
142	1880 360083	Plate	2	
143	Q150B1035	Screw	2	
144	Q40310	Spring washer	2	
145	Q340B10	Nut	2	
146	Q40110	Washer	2	
147	WG9718360041	Support ass.	1	
151	WG9000361323	"L" Connector	1	
153	AZ9003179032	Protection sleeve	150	
154	AZ9003179032	Protection sleeve	150	


				STANDARD	5-1-06
辅助用气储气筒装置/Air Supply Device				PERS	5-011
REP	NUM_ART	DESC	QTY		
01	WG9000360716	Air reservoir (20L)	1		
02	WG9719360020	Bracket	1		
03	Q150B1030	Screw	4		
04	Q40110	Washer	4		
05	Q40310	Spring washer	4		
06	WG9000361402	Draining valve	1		
07	WG9719360024	Tension strap	2		
08	Q218B0880	Screw	2		
09	WG700 550013	Tension bolt	2		
10	WG9000360519	Over-flow valve	1		
11	WG09 190017	Tension bolt	2		
12	WG9000361201	Connector	1		
13	WG9000361204	Connector	3		
14	WG9000361406	"T" Connector	1		
15	190003559385	Connector	1		


			STANDARD	6-1-01
CAB ASSY			PERS	6-001
REP	NUM_ART	DESC	QTY	
01	AZ1646900003	Cab Assy	1	



			STANDARD	6-1-02
CAB Empty			PERS	6-002
REP	NUM_ART	DESC	QTY	
01	AZ1646100014	Cab Body(with doors)	1	
02	AZ1646180015	Cab body	1	
03	AZ1642210001	Door ass.-left	1	
04	AZ1642210002	Door ass.-right	1	
05	Q1840825	Screw	6	
06	Q1840825	Screw	6	
07	AZ1642210009	Hinge ass.	2	
08	AZ1642210009	Hinge ass.	2	


				STANDARD	6-1-05
SWITCHBOARD				PERS	6-005
REP	NUM_ART	DESC	QTY		
01	WG1642160010	Sealing	1		
03	AZ1642160011	Air pipe -left	1		
08	AZ1642160014	Air pipe -right	1		
13	WG1646160017	Air pipe -right bottom	1		
20	AZ1646160022	Bracket	1		
22	WG1646160023	Air pipe - left bottom	1		
27	AZ1642160025	Air pipe -front	1		
36	WG1646160031	Air pipe -right	1		
41	WG1646160037	Air pipe -left	1		
44	AZ1646160039	Bracket	1		
48	WG1646160042	Air pipe - middle rear	1		
53	WG1642160047	Front handle -left	1		
56	WG1642160050	Front handle -right	1		
59	WG1642160052	Rear handle	2		
62	AZ1642160060	Support seat -left	1		
66	AZ1642160062	Support seat -right	1		
70	AZ1646161064	Crossmember ass	1		
139	AZ1646160109	Bracket	1		
150	WG1646160120	Dashboard ass. -right	1		
164	WG1646160139	Panelling -middle	1		
167	WG1646160124	Cover - cup bracket	1		
175	AZ1642930011	Combination screw	2		
179	AZ1642160146	Pinbase	2		
181	AZ1642160150	Air outlet	4		
182	WG1646160171	Dashboard ass. -left	1		
196	WG1646160172	Side cover	1		
203	AZ1642930620	Combination screw	1		
204	WG1646160176	Panelling -left	1		
206	AZ1642160137	Clip	5		
207	WG1646160177	Cover	1		




				STANDARD	6-1-05
SWITCHBOARD				PERS	6-006
REP	NUM_ART	DESC	QTY		
220	AZ1642160181	Bracket	3		
223	AZ1646160181	Bracket	2		
227	WG1646160183	Cover	1		
233	WG1646160186	Cover for hand brake	1		
238	AZ1646160188	Bracket	1		
241	WG1646160190	Switch panel	1		
251	WG1646160213	Cover	1		
254	WG1646160214	Facing	1		
256	WG1646160216	Cover	1		
259	WG1646161217	Protection cover - bottom	1		
261	WG1642930009	Nut	1		
276	WG1646160230	Protect cover -right	1		
284	WG1646160233	Panelling -right	1		
287	WG1646160235	Panelling -left	1		
290	WG1646160238	Cover	1		
292	WG1646160239	Cover	1		
294	AZ1642930010	Cover	3		
297	WG1646160242	Storage box	1		
299	AZ1642160243	Ashtray ass.	1		


		STANDARD	6-1-07
驾驶室工具箱/Tool Box		PERS	6-008

REP	NUM_ART	DESC	QTY
01	WG1642290006	Sealing	2
05	WG1642770006	Cover ass.	2
07	WG1642290002	Hinge ass.	4
09	WG1642290003	Lock ass.	1
11	WG1642290005	Lock pin ass.	2
13	WG1642290004	Plate	4
15	Q1840612	Screw	24
16	Q218B0612	Screw	8
17	Q218B0616	Screw	4
18	Q68208	Clip	2
20	Q40205	Washer	2
21	WG1642290007	Lock ring	2
25	Q2714816F31	Screw	2




				STANDARD	6-1-08
驾驶室车门附件/Door Accessories				PERS	6-009
REP	NUM_ART	DESC	QTY		
01	WG1642330003	Window lifter -left	1		
02	WG1642330004	Window lifter -right	1		
03	WG1642330015	Sealing	2		
04	WG1642330009	Glass guide -left	1		
05	WG1642330010	Glass guide -right	1		
06	AZ1642330019	Protection	4		
07	WG1642330013	Sealing - outside	2		
08	WG1642330011	Sealing - inside	2		
09	WG1642330060	Door glass -left	1		
10	WG1642330061	Door glass -right	1		
11	AZ1642930050	Plug	2		
12	Q2140610	Screw	4		
13	Q2140612	Screw	18		
14	AZ1642330051	Plasticon	2		
15	WG1642330001	Handle	2		
16	Q2140620	Screw	12		
17	WG1642930007	Cover	8		
18	WG1642930006	Rivet	14		
19	WG1642930005	Rivet	14		
20	WG1642330020	Internal lining -left door	1		
21	WG1642330040	Internal lining -right door	1		
22	Q43108	Ring	4		


		STANDARD	6-1-09
门锁/Door Lock		PERS	6-010
REP	NUM_ART	DESC	QTY
00	WG1642341001	Lock assembly	2
01	WG1642340020	Bearing for aux.support	2
02	Q2540820	Screw	8
03	WG1642340021	Pin	2
04	Q2540830	Screw	4
05	WG1642340012	Latch left	1
05a	WG1642340013	Latch right	1
06	WG1642340014	Lock left	1
06a	WG1642340015	Lock right	1
07	WG1642340028	Cable	2
08	Q150B0612	Screw	2
09	Q2300612	Comb.screw	4
10	WG1642340033	Inter handle	2
11	WG1642340031	Aux.lock	2
12	WG1642340032	Cover	2
13	Q150B0616	Screw	8
14/A	WG1642340101	Left outer handle	1
14A/A	WG1642340102	Right outer handle	1
15	WG1642340002	Washer	2
16	WG1642340011	Key	2
17	WG1642340018	Control rod	1
17a	WG1642340029	Control rod	1
18	WG1642341010	Lock ass. (door lock+fuel tank cov	1
19	WG1642340016	Control rod I	2
20	Q2540820	Screw	4
21	WG1642340022	Bracket	2
22	WG1642340023	Plate	2



		STANDARD	6-1-09
门锁/Door Lock		PERS	6-011


REP	NUM_ART	DESC	QTY
23	WG1642340010	Lock piece	2
24	WG1642340024	Pin	2
25	WG1642340030	Rubber sleeve	2
26	WG1642340026	Strap	2
27	Q5100835	Bolt	2
28	Q5002526	Split pin	2
29	WG1642340027	Fixing plate	2
30	Q2140612	Screw	4
31	Q41806	Washer	4




				STANDARD	6-1-10
驾驶室角窗/Corner Window				PERS	6-012
REP	NUM_ART	DESC	QTY		
01	WG1642350001	Sealing -left	1		
02	WG1642350002	Sealing -right	1		
03	WG1642350003	Glass -left	1		
04	WG1642350004	Glass -right	1		

		STANDARD	6-1-11
Driver's seat		PERS	6-013


REP	NUM_ART	DESC	QTY
02	AZ1646510021	Driver's seat-right	1
05	AZ1642930020	Washer	4
09	AZ1646510022	Driver's seat-left	1
12	AZ1642930020	Washer	4
16	WG1642510009	Seat base	1
18	Q340B10F31	Nut	4
19	Q40010F31	Washer	4
20	Q218B0820F31	Screw	4
21	WG1642510008	Seat base	1
23	Q340B10F31	Nut	4
24	Q40010F31	Washer	4
25	Q218B0820F31	Screw	4




				STANDARD	6-1-12
驾驶室安全带/Safety Belt				PERS	6-014
REP	NUM_ART	DESC	QTY		
01	WG1642560010	Safety belt	2		

		STANDARD	6-1-13
驾驶室卧铺/Sleeper		PERS	6-015


REP	NUM_ART	DESC	QTY
01	AZ1643570001	Sleeper	1
04	WG1646570010	Sleeper support	1
06	WG1643570010	Sleeper support	1
10	Q1460825F31	Combination	4
12	Q2714225F31	Screw	6
13	Q40204F31	Washer	6



				STANDARD	6-1-14
驾驶室内饰 /Internal Lining For cab				PERS	6-016
REP	NUM_ART	DESC	QTY		
01	WG1642610001	Roof Panelling	1		
04	WG1642610032	Guide for front curtain	1		
07	WG1642610003	Curtain Guide -right	1		
09	WG1642610004	Curtain Guide -left	1		
12	WG1642610006	Rear panelling	1		
14	190003172951	Rivet	2		
15	WG1642610007	Panelling -left	1		
17	WG1642610008	Strap -left rear	2		
19	WG1642610028	Strap -left	2		
21	WG1646610001	Panelling -right	1		
23	WG1642610011	"A" pole panelling -left	1		
25	WG1642610012	"A" pole panelling -right	1		
27	WG1642610013	Sealing	2		
29	WG1642610016	Seat	4		
32	WG1642610017	Cover for handle	4		
34	116000770023	Hook	2		
35	WG1642610019	Strap	1		
38	AZ1642610014	Nut	4		
39	WG1642610018	Frame	1		
46	Q2713519F31	Screw	13		
58	Q2713519F31	Screw	4		
60	AZ1642610050	Curtain	1		
61	AZ1642610025	Curtain hook	30		
62	WG1642610034	Block	4		


		STANDARD	6-1-15
驾驶室地板垫/Floor Lining		PERS	6-017

REP	NUM_ART	DESC	QTY
01	WG1646620001	Floor lining -left	1
06	WG1642620006	Sill -left	1
09	WG1642620007	Sill -right	1
12	WG1646620003	Heat insulation lining -left	1
15	WG1646620006	Floor lining -right	1
17	WG1642620003	Floor lining -rear	2
19	WG1646620008	Carpet for engine hood	1
21	Q2744222F31	Screw	3
22	Q2744222F31	Screw	3
23	WG1646620007	Heat insulation lining -right	1




		STANDARD	6-1-16
驾驶室隔音板/Sound Insulation Slab		PERS	6-018

REP	NUM_ART	DESC	QTY
01	WG1642690001	Sound Insulation Slab	1
02	WG1642690003	Front support rod	1
03	WG1642690005	Middle rear support rod	1
04	WG1642690015	Middle rear support rod	1
05	WG1642690006	Rubber pad	1
06	Q2714819F31	Screw	1
07	Q68610	Clip	1




			STANDARD	6-1-17
驾驶室玻璃/Windshield			PERS	6-019
REP	NUM_ART	DESC	QTY	
01	WG1642710001	Windshield	1	
02	WG1642710002	Sealing	1	
03	WG1642710005	Rear glass	1	
04	WG1642710006	Sealing	1	





		STANDARD	6-1-18
驾驶室上杂品箱/Upper Box		PERS	6-020

REP	NUM_ART	DESC	QTY
01	WG1642770010	Sun visor	2
02	Q2714825F31	Screw	8
03	Q2714216F31	Screw	26
04	WG1642770015	Horn cover-left	1
05	AZ1642770017	Bush	22
06	WG1642770012	Cover	1
07	WG1642770017	Horn cover-middle	1
08	WG1642770013	Cover	2
09	115200160098	Key	2
10	115200160094	Lock	2
11	WG1642770016	Horn cover-right	1
12	WG1642770014	Box	2
13	Q2714816F31	Washer	12
14	WG1642770018	Hinge	4



			STANDARD	6-1-19
顶窗盖装置/Roof Hatch			PERS	6-021
REP	NUM_ART	DESC	QTY	
01	WG1642770006	Cover ass.	1	
02	WG1642770008	Roof panelling	1	
03	WG1642770005	Rivet	4	
04	WG1642770009	Sealing	1	
05	WG1642770011	Hinge	2	
06	Q2140620F31	Screw	6	
07	Q40206F31	Washer	6	
08	WG1642930021	Washer	2	
09	WG1642770007	Switch	1	
10	Q2140620F31	Screw	4	
11	Q40206F31	Washer	4	





				STANDARD	6-1-20
驾驶室遮阳罩/Sun Visor				PERS	6-022
REP	NUM_ART	DESC	QTY		
2	WG1642870231	Sun Visor	1		
4	WG1642870234	Bracket -right middle	1		
6	WG1642870235	Bracket -left middle	1		
8	AZ1608870008	Spacer	4		
9	AZ1642870043	Rubber cushion	4		
10	Q2140625	Screw	4		
11	Q40206	Washer	4		
12	Q340B06	Nut	4		
13	AZ1672870121	Rubber cushion	4		
14	Q150B0820	Screw	4		
15	Q40208	Washer	4		
16	WG1642870232	Bracket -right	1		
18	WG1642870233	Bracket -left	1		
20	AZ1608870008	Spacer	4		
21	AZ1642870043	Rubber cushion	4		
22	Q2140625	Screw	4		
23	Q40206	Washer	4		
24	Q340B06	Nut	4		
25	AZ1672870121	Rubber cushion	4		
26	Q150B0820	Screw	4		
27	Q40208	Washer	4		
28	WG1642870236	Bracket - lower	2		
30	Q150B0820	Screw	2		
31	Q40208	Washer	2		
32	AZ1672870121	Rubber cushion	2		
33	Q150B0825	Screw	2		
34	Q40208	Washer	4		
35	Q340B08	Nut	2		

				STANDARD	6-2-01
FRONT SIDE COVER				PERS	6-201
REP	NUM_ART	DESC	QTY		
02	WG1642110001	Outside Cover ass.-right	1		
02	WG1642110002	Outside Cover ass.-left	1		
06	WG1642110003	Inside Cover-right	1		
06	WG1642110004	Inside Cover-left	1		
10	AZ1642110006	Plate	2		
13	AZ1642110007	Plate-lower right	1		
13	AZ1642110008	Plate-lower left	1		
15	WG9100360134	Spacer	1		
16	199100360134	Spacer	1		
17	Q150B0820	Screw	6		
18	Q40208	Washer	6		
19	Q40308	Spring washer	6		
20	Q150B0620	Screw	10		
21	Q40206	Washer	14		
22	Q40306	Spring washer	14		
23	Q350B06	Nut	4		
24	WG1642110019	Panelling for "A" pole -left	1		
24	WG1642110020	Panelling for "A" pole -right	1		
28	WG1642110021	Clip	1		
31	WG1642110041	Clip	1		
32	WG1642110022	Rivet	6		

		STANDARD	6-2-02
RADIATOR GRILLE		PERS	6-202


REP	NUM_ART	DESC	QTY
34	WG1642110016	Hinge seat	2
36	AZ1642110032	Hinge ass. -left	1
39	AZ1642110033	Hinge ass. -right	1
42	AZ1642110017	Hinge pin	2
43	WG1642110013	Front cover	1
45	Q150B0616	Screw	8
46	Q40206	Washer	8
47	WG1642110027	Lock ass. -right	1
49	Q150B0616	Screw	5
50	Q40206	Washer	5
52	WG1642110028	Lock ass. -left	1
54	Q150B0616	Screw	5
55	Q40206	Washer	5
57	AZ1642110014	Bracket	2
60	Q150B0816	Screw	2
61	Q40208	Washer	2
62	WG1642110018	Strip	4
66	Q218B0860	Screw	4
67	Q40008	Washer	4
68	WG1642110024	Spring	2
70	WG9100360134	Spacer	4
72	Q5002014	Split pin	2
73	WG1642110212	Logo	1
75	WG1646110001	Plate	1
77	WG1642930003	Plug	4




				STANDARD	6-2-03
中长驾驶室翼子板/Fender				PERS	6-203
REP	NUM_ART	DESC	QTY		
01	WG1642230105	Fender ass. -left front	1		
02	WG1642230106	Fender ass. -right front	1		
03	WG1642230107	Fender ass. -left rear	1		
04	WG1642230108	Fender ass. -right rear	1		
05	Q150B1030F31	Screw	4		
06	Q40210F31	Washer	10		
07	Q40310F31	Spring washer	4		
08	Q340B10F31	Nut	4		
09	WG1642230121	Bracket - left	1		
10	WG1642230122	Bracket - right	1		
11	Q40206F31	Washer	6		
12	Q2714816F31	Screw	6		
13	Q40006F31	Washer	36		
14	Q150B0625F31	Screw	12		
15	Q40106F31	Washer	12		
16	Q40306F31	Spring washer	32		
17	Q2540830F31	Screw	8		
18	WG1642230109	Antiskid plate -left	1		
19	WG1642230110	Antiskid plate -right	1		
20	Q33210F31	Nut	4		
21	Q40110F31	Washer	4		
22	Q340B06F31	Nut	10		
23	Q150B0630F31	Screw	2		
24	WG1642230041	Strip	2		

		STANDARD	6-2-04
前轮后翼子板/Rear Fender		PERS	6-204

REP	NUM_ART	DESC	QTY
01	WG1642230103	Rear Fender -left	1
05	WG1642230111	Pad	2
07	WG1642230008	Washer	18
09	Q2714216	Screw	18
10	Q150B0860	Screw	8
11	Q40208	Washer	8
12	Q40308	Spring washer	8
13	Q340B08	Nut	8
14	WG1642233001	Rear Fender -right	1




			STANDARD	6-2-05
后翼子板支架/Bracket for Rear Fender			PERS	6-205
REP	NUM_ART	DESC	QTY	
01	WG9719930313	Bracket - left	1	
03	WG9719930315	Bracket - right	1	
05	Q150B16100	Screw	4	
06	Q33216	Nut	4	



		STANDARD	6-2-06
后挡泥板/Rear Mudguard		PERS	6-206


REP	NUM_ART	DESC	QTY
01	Q40210F31	Washer	10
02	Q40206F31	Washer	36
03	Q150B0625F31	Screw	12
04	Q340B06F31	Nut	10
05	Q150B0820F31	Screw	8
06	Q40208F31	Washer	8
07	Q40308F31	Spring washer	8
08	AZ1641230027	Strip	2
09	WG1641230025	Mudguard -left	1
10	WG1641230026	Mudguard -right	1



			STANDARD	6-2-07
驾驶室通用件/Common Parts			PERS	6-207
REP	NUM_ART	DESC	QTY	
01	WG1642930001	Cover	2	
02	WG1642930002	Sealing	2	




		STANDARD		6-3-01
FRONT SUSPENSION OF DRIVER 轿 CAB/驾驶室前悬置		PERS		6-301
REP	NUM_ART	DESC	QTY	
02	AZ1642430219	Turn shaft	1	
07	AZ1642430061	Bush	2	
08	AZ1642430071	screw	2	
09	Q700B06	grease napple	2	
10	WG1642430072	washer	2	
12	190003888459	nut	2	
13	WG1642430385	front shock absorber	2	
15	AZ1642430265	bush	2	
16	Q1841490	screw	2	
17	Q33014	locking nut	2	
18	AZ1642430233	front bracket left	1	
19	Q151B1645	screw	5	
20	190003888459	locking nut	5	
21	AZ1642430234	front bracket right	1	
22	Q151B1645	screw	6	
22	Q151B1655	screw	1	
23	190003888459	locking nut	7	
24	Q151B1450	screw	3	
25	190003888458	locking nut	3	
26	AZ1642430263	bush	2	
27	AZ1642430235	plate	2	
28	Q40312	spring washer	4	
29	Q150B1245	screw	4	
30	AZ1642430083	stop	2	
31	AZ1642430239	shaft	2	
32	Q2861030	nail	2	
33	Q340B10	nut	2	



				STANDARD	6-3-02
REAR SUSPENSION OF DRIVER'S CAB/驾驶室后悬置				PERS	6-302
REP	NUM_ART	DESC	QTY		
02	AZ1642440011	Bottom bracket left	1		
03	AZ1642440012	Bottom bracket right	1		
04	Q151B1445	screw	8		
05	190003888458	locking nut	8		
06	WG1642430081	stop	2		
10	WG1642430082	washer	2		
12	Q40310	spring washer	2		
13	Q340B10	nut	2		
14	WG1642440382	Shock absorber	2		
16	Q1841480	screw	2		
17	Q33014	nut	2		
18	WG1642440101	Hyd.lock	2		
20	Q1841480	screw	2		
27	Q33014	locking nut	2		
22	AZ1642440021	shock absorber	2		
23	WG1642440031	bush	2		
24	WG1642440032	bush	2		
27	Q18414100	screw	2		
26	Q18414140	screw	2		
29	Q33014	locking nut	4		
30	WG1642440040	Above bracket left	1		
28	WG1642440041	Above bracket right	1		
32	Q1841230	screw	8		
35	WG1642440052	Sensor for cab lock	2		
37	Q150B0630	screw	4		
38	AZ1642440069	plug	1		
39	199014280016	bush	1		
40	190003559561	clamp	1		
41	190003559516	nut	1		
42	WG1642440070	connector	1		


		STANDARD	6-3-02
REAR SUSPENSION OF DRIVER'S CAB/驾驶室后悬置		PERS	6-303


REP	NUM_ART	DESC	QTY
44	190003559561	clamp	1
45	190003559516	nut	1
46	WG1642440071	hose	1
48	190003171356	plastic strap	5




		STANDARD	6-3-03
驾驶室举升装置（改进型前悬右置车）/Tilting Equipment		PERS	6-305

REP	NUM_ART	DESC	QTY
66	WG9719820207	Hose	1
68	WG9719820203	Hose	1
70	WG9719820204	Hose	1
72	WG9719820008	Shaft	1
74	WG9719820009	Bush	1
76	WG9719820012	Bush	2
78	AZ9003963001	Grease nozzle	1
79	AZ9003963010	Grease nozzle	1
80	Q700B06	Grease nozzle	1
81	AZ9003963001	Grease nozzle	1
82	AZ9003963010	Grease nozzle	1
83	Q700B06	Grease nozzle	1
85	WG9003171356	Fastener	15
87	WG9719820015	Shaft	1




				STANDARD	6-3-03
驾驶室举升装置（改进型前悬右置车）/Tilting Equipment				PERS	6-304
REP	NUM_ART	DESC	QTY		
02	WG9719826001	Hydr. Hand pump	1		
04	Q150B1020	Screw	2		
05	Q40310	Spring washer	2		
06	WG9719820002	Hydr. Cylinder	1		
16	190003559482	"T" connector	1		
23	WG9719820011	Washer	1		
25	Q40124	Washer	2		
27	Q33424	Nut	2		
28	WG9719820013	Washer	2		
32	AZ1642430011	Plate	1		
33	AZ1642430291	Bucket	1		
34	AZ1642430292	Plate	1		
35	AZ9719820023	Plate	1		
36	Q151C1235	Screw	7		
37	190003888457	Nut	7		
38	AZ9719820021	Upper brace	1		
39	Q5101428	Shaft	1		
40	Q40114	Washer	1		
41	Q5004028	Split pin	1		
42	Q41814	Spring washer	1		
43	AZ9719820022	Lower brace	2		
44	190003903452	Shaft	1		
45	Q41710	Spring washer	1		
46	Q5003216	Split pin	1		
47	Q5004028	Split pin	1		
49	Q5101428	Shaft	1		
50	Q40114	Washer	1		
51	Q5004028	Split pin	1		
52	Q41814	Spring washer	1		
64	WG9719820206	Hose	1		


				STANDARD	6-3-04
自卸车金属保险杠及前牵引装置/Bumper & Front Towing				PERS	6-306
REP	NUM_ART	DESC	QTY		
02	AZ9725930157	Front towing hook base	1		
03	AZ9114930094	Front towing hook ass.	1		
11	WG9114930093	Front towing hook	1		
13	Q151B1660	Screw	4		
14	190003888459	Nut	4		
15	Q151B1465	Screw	3		
16	190003888458	Nut	3		
17	AZ9725930711	Bracket	1		
25	Q1841075	Screw	4		
26	Q1841025	Screw	4		
27	Q40210	Washer	8		
28	Q40310	Spring washer	8		
29	AZ9725930710	Support plate	4		
30	Q150B1045	Screw	8		
31	Q40210	Washer	16		
32	Q33210	Nut	8		
33	AZ9725930088	Plate - left	1		
34	AZ9725930089	Plate - right	1		
35	Q150B1035	Screw	4		
36	Q40210	Washer	8		
37	Q33210	Nut	4		
38	WG9725930029	Upper support plate	1		
40	AZ9725930034	Bracket - middle	1		
44	Q2540820	Screw	1		
45	Q40308	Spring washer	1		
46	Q340B08	Nut	1		
47	Q150B0880	Screw	1		
48	Q40208	Washer	2		
49	Q33208	Nut	1		
58	AZ1641240026	Plate - right	1		

				STANDARD	6-3-04
自卸车金属保险杠及前牵引装置/Bumper & Front Towing				PERS	6-307
REP	NUM_ART	DESC	QTY		
59	AZ1641240027	Plate - left	1		
60	Q1840840	Screw	2		
61	Q150B0822	Screw	4		
62	Q40208	Washer	8		
63	Q40308	Spring washer	6		
64	Q340B08	Nut	6		
65	AZ1642240050	Panelling -left	1		
66	AZ1642240051	Panelling -right	1		
67	WG1642930009	Nut	4		
69	Q2714819	Screw	4		
70	Q40206	Washer	4		
72	WG1641240114	Lower step - right	1		
74	WG1641240113	Lower step - left	1		
76	WG1641240115	Anti-sliding plate - left	1		
78	WG1641240116	Anti-sliding plate - right	1		
80	Q340B08	Nut	8		
81	Q2540835	Screw	8		
98	AZ1641241003	Bumper ass.	1		
111	WG1641240035	Plate-left	1		
113	WG1641240036	Plate -right	1		
115	WG1641240037	Plate -middle	2		

		STANDARD	6-4-01
空调制冷压缩机及皮带/Compressor and Belt		PERS	6-401


REP	NUM_ART	DESC	QTY
14	WG1500139001	Compressor	1
16	WG581C 160018	Bush	2
22	WG1500130027	Block	1
25	WG1500130017	Belt	1
27	WG1500090026	Screw	1
29	190003800568	Screw M10x100xp1.5	1
30	190003888452	Nut	1
31	190012630006	Nut	2
32	190003935015	Washer	2
33	190003931162	Spring washer	1



		STANDARD		6-4-02
DRIVER'S CAB HEATING/驾驶室暖风装置		PERS		6-402
REP	NUM_ART	DESC	QTY	
01	AZ1630840002	Evaporator	1	
03	AZ1630840062	Rubber sleeve	2	
04	Q2714825	Screw	2	
04a	Q40206	Washer	2	
05	190003989340	Circlip	6	
06	WG1642840091	Hose I	2	
07	AZ1642848613	Steel pipe	1	
08	Q1840816	Screw	1	
09	AZ1642840084	Protect net	1	
10	Q150B0620	Screw	2	
10a	Q40206	Washer	2	
11	Q1840825	Screw	1	
11a	Q33008	Nut	1	
12	WG1642840092	Hose II	2	
13	Q150B0640	Screw	6	
13a	Q40306	Spring washer	6	
13b	Q40206	Washer	6	
14	WG1642820010/2	Aftercooler assembly	1	
15	WG1642820011	Bracket left for condenser	1	
15	WG1642820012	Bracket right for condenser	1	
16	Q150B0825	Screw	4	
16a	Q40308	Spring washer	8	
16b	Q40208	Washer	4	
16c	Q340B08	Nut	4	
17	WG1642820027/2	Condenser-receiver connect tube	1	
18	WG1642820029/2	Evaporator-compressor connect tube	1	
19	Q150B0625	screw	2	
19	Q40306	Spring washer	2	
19	Q40206	Washer	2	
20	WG1642820025/2	Receiver tank	1	


		STANDARD	6-5-01
View Mirror		PERS	6-501


REP	NUM_ART	DESC	QTY
01	WG1646770001	Rear view mirror left	1
04	WG1646770002	Rear view mirror right	1
07	Q2140630	screw	10
08	Q2140625	screw	2
09	Q40306	spring washer	12
10	Q40106	washer	1
11	Q340B06	nut	2



		STANDARD	6-5-02
View Mirror		PERS	6-502


REP	NUM_ART	DESC	QTY
13	WG1600770007	Side mirror	1
15	AZ1642770098	plate	1
16	Q218B0616	screw	2
17	Q2540620	screw	2
18	Q40306	spring washer	2



		STANDARD		6-5-03
View Mirror		PERS		6-503
REP	NUM_ART	DESC	QTY	
19	WG1642770004	bottom mirror	1	
20	AZ1646770054	bracket	1	
21	Q340B08	nut	2	
22	Q40208	washer	4	
23	Q150B0825	screw	2	
24	Q40308	spring washer	2	
27	Q40306	spring washer	12	


		STANDARD	6-5-04
WINDSCREEN WIPER/雨刮器		PERS	6-504


REP	NUM_ART	DESC	QTY
00	WG1646741001	Wiper	1
01	WG1646741009	Rod	1
02	WG1646741010	Wiper arm and rubber assy	1
03	WG1642740011	Wiper BLADE	1
04	WG1646741008	Wiper anchor	1
11	Q150B0816	Screw	4
12	Q40208	Washer	4
14	Q150B0812	Screw	4
15	Q40308	Spring washer	4
16	Q40108	Washer	4







		STANDARD	6-5-05
驾驶室风窗洗涤器/Windscreen Washing Equipment		PERS	6-505


REP	NUM_ART	DESC	QTY
02	WG1642860011	Washing Equipment	1
2.1	WG1642860011+001/1	Pump	1
05	WG1642861010	Bracket	1
10	Q340B06	Nut	2
17	Q150B0820	Screw	2




				STANDARD	7-1-01
电气控制系统(VDO)				PERS	7-101
REP	NUM_ART	DESC	QTY		
01	AZ9724580002	CBCU安装板	1		
02	Q2714216	十字槽盘头自攻螺钉	2		
03	WG9716580023	中央控制单元（CBCU）	1		
05	Q2140512	十字槽盘头螺钉	3		
06	Q40105	平垫圈	3		
07	WG9716580025	组合仪表（CMIC）	1		
09	Q2714816	十字槽盘头自攻螺钉	4		
10	Q40105	平垫圈	4		
11	Q2714216F31	十字槽盘头自攻螺钉	2		
12	Q340B05	1型六角螺母	3		
13	Q340B05	1型六角螺母	3		
14	Q2714816F31	十字槽盘头自攻螺钉	4		


				STANDARD	7-1-02
自卸车电器装置				PERS	7-102
REP	NUM_ART	DESC	QTY		
02	WG9719584011	灯光开关	1		
04	WG9719584012	前雾灯开关	1		
06	WG9719584013	后雾灯开关	1		
08	WG9719584004	危急报警开关	1		
10	WG9719584015	喇叭开关	1		
12	WG9719582010	取力器开关	1		
14	WG9719582011	轮差开关	1		
16	WG9719582012	轴差开关	1		
18	WG9725580005	诊断接口外壳	1		
20	WG9719582054	MCS旋钮	1		
22	WG9719582056	发动机制动开关	1		
24	WG9900580021	盖板	6		
26	WG9725586002	组合开关（右置车）	1		
28	Q2140512	十字槽盘头螺钉	3		
29	AZ9725580030	橡胶堵盖	1		
30	WG9100580142	24V点烟器	1		
32	WG9725584026	线束固定夹	1		
34	WG9725584029	ECU安装箱	1		
36	Q150B0825	六角头螺栓	5		
37	Q40108	平垫圈	5		
38	Q40308	弹簧垫圈	5		
39	Q340B08	1型六角螺母	5		
40	WG9716580021	电气接线盒总成	1		
43	Q2140635	盘头螺钉	4		
44	Q40106	平垫圈	5		
45	Q2140610	十字槽盘头螺钉	1		
46	Q2140510	十字槽盘头螺钉	2		
47	Q40105	平垫圈	2		
48	Q2140516F31	十字槽盘头螺钉	2		
49	Q40105F31	平垫圈	2		




		STANDARD		7-1-02
自卸车电器装置		PERS		7-103
REP	NUM_ART	DESC	QTY	
50	Q2140616F31	十字槽盘头螺钉	1	
51	Q40106F31	平垫圈	2	
52	WG9725584001	40A常开式继电器	3	
54	WG9725584002	20A常开式继电器	7	

			STANDARD	7-1-03
底盘电器			PERS	7-104
REP	NUM_ART	DESC	QTY	
02	WG9718710002	盆形电喇叭	1	
04	Q1460825	六角头螺栓、弹簧垫圈和平垫圈组合	1	
05	Q340B08	1型六角螺母	1	
06	WG9100710004	气压信号灯开关	2	
08	WG9725710004	支架	1	
10	Q2140620F31	十字槽盘头螺钉	2	
11	Q40306	弹簧垫圈	2	
12	WG9727710002	电子式气压传感器	2	
14	WG9719710004	电磁阀(P99接头)	4	
16	Q150B0875	六角头螺栓	2	
17	Q150B08190	六角头螺栓(螺纹有效长度>35mm)	2	
18	Q40308	弹簧垫圈	4	
19	Q340B08	1型六角螺母	4	
20	WG9725584002	20A常开式继电器	1	
22	Q2140410	十字槽盘头螺钉	1	
23	Q40304	弹簧垫圈	1	
24	Q40104	平垫圈	1	
25	WG9725580086	铅封	1	
27	190000810930	铅封线	40	
28	WG9725580006	100A保险装置	1	
31	Q150B0620	六角头螺栓	2	
32	Q40306	弹簧垫圈	2	
33	Q40106	平垫圈	2	
34	Q340B06	1型六角螺母	2	




				STANDARD	7-1-04
蓄电池				PERS	7-105
REP	NUM_ART	DESC	QTY		
01	AZ9725760005	HOWO电瓶箱体总成	1		
02	AZ9100760110	电瓶箱锁总成	2		
03	AZ9100760111	电瓶箱锁拉钩	1		
04	AZ9100760112	电瓶箱锁拉环	1		
05	AZ9725760003	HOWO电瓶箱体总成	1		
06	Q151B1645	六角头螺栓	4		
07	Q151B1650	六角头螺栓	4		
08	190003888459	自锁螺母	8		
09	AZ9100760102	电瓶箱盖	1		
10	AZ9100760104	压板	2		
11	Q340B08	1型六角螺母	6		
12	Q40208	大垫圈	6		
13	Q40308	弹簧垫圈	6		
14	1682 110021	橡胶缓冲块	6		
15	AZ9100760108	下橡胶垫板	1		
16	WG9100760100	电源总开关	1		
18	199100760099	密封垫	1		
19	Q150B0835	六角头螺栓	2		
20	Q40308	弹簧垫圈	2		
21	Q40108	平垫圈	2		
22	Q340B08	1型六角螺母	2		
23	AZ9719770058	橡胶过孔护圈 (Φ50/Φ35)	2		
24	Q150B0620	六角头螺栓	2		
25	AZ9725760007	电器连接板装配图	1		
26	AZ9925760004	电器连接板	1		
27	Q150B0814	六角头螺栓	4		
28	Q33208	2型全金属六角锁紧螺母	4		

				STANDARD	7-2-01
右置车尾灯电线束				PERS	7-201
REP	NUM_ART	DESC	QTY		
01	AZ9716770064	左组合后灯电线束75 (BW)	1		
02	AZ9716770065	右组合后灯电线束165 (BW)	1		


			STANDARD	7-2-02
轮、轴间差速锁电线束			PERS	7-202
REP	NUM_ART	DESC	QTY	
01	AZ9725770094	轮、轴差速锁电线束30（右置/BW）	1	




			STANDARD	7-2-03
车架电线束			PERS	7-203
REP	NUM_ART	DESC	QTY	
04	AZ9725776034	车架电线束	1	




		STANDARD		7-2-04
起动机负极至后分线盒搭铁线		PERS		7-204
REP	NUM_ART	DESC	QTY	
01	AZ9725770075	起动机负极至后分线盒搭铁线	1	



		STANDARD	7-2-05
起动机电线		PERS	7-205
REP	NUM_ART	DESC	QTY
09	AZ9721778202	起动机电线束(1520)	1
			

		STANDARD		7-2-06
驾驶室电线		PERS		7-206
REP	NUM_ART	DESC	QTY	
09	AZ9721770161	右置HW7E驾驶室电线束	1	



		STANDARD		7-2-07
右置HW7E自卸车底盘电线(双桥)		PERS		7-207
REP	NUM_ART	DESC	QTY	
04	AZ9721770372	右置HW7E自卸车底盘电线(双桥)	1	

与驾驶室对插

空气干燥器

电瓶负极搭铁

电瓶箱

储气筒

4

水温油压传感器

发电机

变速箱对插

电磁阀

燃油箱

